OUTDOOR TECH®

TURTLE SHELL® 4.0
RUGGED
WIRELESS
WIRELESS PAIRING
BOOM
BOX

SHOCK PROOF   WATERPROOF   POWER BANK

Hi

Good call on picking up the Outdoor Tech® Turtle Shell® 4.0 wireless boom box. Your experience of the universe will soon be enhanced wirelessly and powerfully. This manual exists to help make sure that you use it correctly, so you're definitely going to want to relax for a hot second and look through this.

Kisses,

OUTDOOR TECH®

CONTENTS

ANATOMY

A. Power On / Power Off
B. Multi Function Button
C. Skip Backward / Volume Down
D. Skip Forward / Volume Up
E. USB C Charge Port/ 3.5 mm Aux Port
F. USB C Output Charge Port
G. Microphone
H. Light Indicator

1

POWER UP

TO CHARGE

For best results, fully charge your Turtle Shell® 4.0 before use!

1. Connect the included USB C to a power source and the charging port on the Turtle Shell® 4.0. When charging, the red LED light will stay activated. ***Full charge time is about 4-5 hours.

2. When the Turtle Shell® 4.0 is fully charged, the RED light will turn off.

The displayed battery meter is supported for Apple products.

*The Turtle Shell® 4.0's Bluetooth and music functions can still operate while charging.

2

MUSIC FUNCTIONS

Music / Device Controls

Skip backward   MFB   Skip forward
Volume down   Volume up

FUNCTION	BUTTON	ACTION
Power on		Press 3 sec
Power off		Press 2 sec
Transmit mode		Hold 2 sec
Receiver mode		Hold 2 sec
Manual pairing mode		Hold for 3 sec
Play / Pause		Short press once
Volume up		Short press once
Volume down		Short press once
Skip forward		Press & hold for 2 sec
Skip backward		Press & hold for 2 sec

3

PHONE FUNCTIONS

Device Controls

Skip backward   MFB   Skip forward
Volume down   Volume up

FUNCTION	BUTTON	ACTION
Answer an incoming call		Short press once
Reject an incoming call		Press & hold for 2 sec
End call		Short press once
Siri/Voice activation		Press & hold for 2 sec & release

4

▉ PAIRING TO DEVICE

Power On / Off
ON: Hold the Power Button for 2-3 seconds or until the LED light flashes blue and the voice prompt states "Power on"

OFF: Hold the Power Button for 3-4 seconds or until the LED light flashes red and the voice prompt states "Power off"

Enter Pairing Mode
When powered on hold the "+" and "-" at the simultaneously for 2-3 seconds or until you see the LED light flash blue 3 times and the voice prompt states "Pairing."

Pairing Turtle Shell 4.0 to Device
Open the Bluetooth settings on your device. If you have put your Turtle Shell® 4.0 into pairing mode, it should be listed as "ODT Turtle Shell® 4.0" as an available device to pair. Connect with the Turtle Shell® 4.0 and enter "0000" if prompted. The voice prompt will state "Paired" if the Turtle Shell 4.0 and your device connect.

5

▉ SPEAKER TO SPEAKER PAIRING

TS4 #1   TS4 #2

STEP ONE Transmit Mode
Turn on TS4 #1 and wait till the voice prompt states that the speaker is on. Then press & hold simultaneously the MFB button and the "-" button. TS4 #1 will then state that it is in pairing mode.

STEP TWO Receiver Mode
Turn on TS4 #2 and wait till the voice prompt states that the speaker is on. Then press & hold simultaneously the MFB button and the "+" button. TS4 #2 will then state that it is in pairing mode.

STEP THREE
Once TS4 #1 and TS4 #2 are connected, the voice prompt will state "Di." Then Press "+" and "-" to enter manual pairing mode.

6

▉ LISTEN

The built-in microphone means that the Turtle Shell 4.0 can be used as a wireless headset.

*NOTE: The built-in microphone only works when connected via Bluetooth.

The following are tips on how to use your Turtle Shell 4.0 to speak on the telephone:

Answer a call......... Press the multifunction button.
End a call.............. Press the multifunction button.
Decline a call........ Press and hold the multifuntion button for two seconds.
Make a call........... Use your phone to dial as usual. Listen and talk through the Turtle Shell® 4.0.
Mute..................... Hold the >> and << buttons for 2 seconds, or until you hear a beep.

7

▉ FAQ

Hearing Distortion
A. Lower the volume on your Turtle Shell® 4.0® and / or phone /device.
B. Make sure it's charged up. Check for low battery, then charge if necessary.

Not Loud Enough
A. Turn up the volume on your phone / device or your Turtle Shell® 4.0.
B. Make sure it's charged up.
C. Plug the Turtle Shell in to your phone / device via 3.5mm stereo cable.

Unable to Pair
A. Confirm your phone / device is Blue tooth compatible.
B. Re-Pair: Follow pairing instructions in this guide.

Signal Loss or Dropouts via Bluetooth
A. Move Turtle Shell closer to your phone / device.
B. Make sure it's charged up.
C. Turn off your Turtle Shell® 4.0 and phone / device, then power up and reconnect.

8

▉ SPECS

Rating: IPX7

Bluetooth v 5.0
Bluetooth Profiles: HSP, HFP. A2DP, AVRCP
Compatibility: Bluetooth v 1.1 and above
Operating range: 32 ft
Operating range between speakers: 15 ft
Device name: ODT TURTLE SHELL 4.0

Power source: Lithium ion rechargeable battery cell

Battery capacity: 4000mAh / 14.8 Wh
Charge Output: 5V / 1A
Charge Input: 5V / 2.1A
Playing Time: Up to 18 hrs
Charge Time: ~4.5 hrs

Operating Temperature: 0~45° C
Storage Temperature: -20~60° C
RoHS: Fully RoHS compliant

9

▉ IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Clean only with dry cloth.
6. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
7. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
8. Only use attachments/accessories specified by the manufacturer.
9. Unplug this apparatus during lightning storms or when unused for long periods of time.
10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
11. The apparatus shall be used at maximum 45 ambient temperature.
12. The maximum height above sea level is 2000m 14.
13. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, tablecloths, curtains, etc.
14. No naked flame sources, such as lighted candles, should be placed on the apparatus.
15. Battery pack shall not be exposed to excessive heat such as sunshine, fire or the like.

CAUTION
Danger of explosion if battery is incorrectly replaced, Replace only with the same or equivalent type.

The appliance shall not be disposed together with the normal waste. It must be recycled.

www.outdoortech.com