Calibration

1. **Please have the jumper Jp3 switch OFF**
   before you start to calibrate weight.

2. Press and hold any key while powering **ON**.
   The system goes to **Calibration mode**.

   `[ CAL ]`

3. Press ⟨⟩ key goes to UNITS mode.

   `Uni t.Lb`

   Press ⟨U⟩ key to select Calibrating units in **lb** or **kg**.

   `Uni t.:9`

4. Press ⟨⟩ key goes to CAPACITY mode.

   `r    ]∩∩`

   Press ⟨U⟩ key to select Maxium Capacity.

   `L.]0000`

5. Press ⟨⟩ key goes to SPAN mode.

   (Offset value to be displayed around 5000 ~ 50000)

   `i]LLL`

6. Press ⟨+0+⟩ key to make display to zero.

   `0`

7. Put on the **calibrating weight in lb**.

   (Span value to be 50000 ~ 150000 at full capacity)

   `i]LLLL`

8. Press ⟨⟩ key to cycle through a list of permissible weights.
   When the weight on the scale is displayed, press ⟨⟩ key
   the weight calibrating to be done.

   `]0000`

9. **After finish the weight calibration, make the Jp3 switch ON.**
   Now you are ready to weigh.