Projector Mode
Remove Shroud

Unzip

Undo Velcro

Collapse with Open Back

Undo Buckle

Separate 4 Foldable Arms

Slide Out Projector

How to tilt/flip?

Tripod & 🔄 Flip Button

How to clean?

Sticky Roller

Tape

For more help, contact us at:
founders@arovia.com

Foldable Display
Install Shroud

Push Arms into Sockets

Keep Vertical

Buckle Up

Move Shroud Back Over

Pop-up Unzipped

Zip

Velcro

How to pop up?

Shake

Push until lock

Pull

Pull

Press 3s

- ⊙ Focus dial
- ⟳ Flip image
- − ☼ +
- − ◁ +
- ⏻ Power

Cut-off?

Hold down

Pull

Press down

Pull

Try the Kick-stand

Do NOT push the opposite corner!

Perfect!

How to fold?

Let screen drop down naturally

Fold arms

Fold arms

Fold arms

Keep screen at the bottom

Hold