

US UK

Dear user

Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.
1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

1

OS support

Windows XP/Vista/Win7/Win8/Win10/Win11

Key Function Introduction

FN1 key work with other keys

- 1. FN1+<ESC >= `
2. FN1+ shift+<ESC >= ~
3. FN1+<1~0) >= F1~F10
4. FN1+<-\_>=F11
5. FN1+<+>=F12
6. FN1+<A>=←
7. FN1+<S>=↓
8. FN1+<D>=→
9. FN1+<W>=↑
10. FN1+<P>=PRTSC
11. FN1+<{>=HOME
12. FN1+<}>=END
13. FN1+<:;>=PGUP
14. FN1+<">=PGDN
15. FN1+<.>=INSERT
16. FN1+</?>=DELETE
17. FN1+WIN: Lock Windows key, press it again to unlock
18. FN1+<ESC>: Back to factory setting

FN2 key work with other keys

- 1. FN2+"9" =18 Backlighting modes switchable

2

- 2. FN2+ "0": Turn off backlightink
3. FN2+ "-": Brightness -,total 5 levels
4. FN2+ "+": Brightness+,total 5 levels

Customized backlight for different game

- 1. Press FN2 + "Backspace" key : active backlight record mode
2. Press again FN2 + "Backspace" key: to start record, CAPS key twinkle quickly, press the desired key to light up. Press FN2+ "Backspace" to save and quit.
3. Display customized backlight by press FN2+ "Backspace" key.
4. Delete all customized backlight: press and hold FN1+ "Backspace" key for 5 seconds to delete all customized backlight.

FAQ

- 1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a warm and ventilated place. Make sure the keyboard is dried naturally before the next use



3

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

California Proposition 65

WARNING: Risk of Cancer from [Name of one or more chemicals known to cause cancer] And Reproductive Harm From [Name of one or more chemicals known to cause reproductive toxicity] Exposure - www.P65Warnings.ca.gov

4

DE

Lieber Nutzer

Vielen Dank, dass Sie sich für die Marke REDRAGON entschieden haben. Zum Schutz Ihrer Rechte und für einen optimalen Kundenservice möchten wir Sie bitten, unsere Garantiebestimmungen zu beachten.
1. Innerhalb der Garantiezeit sind Reparaturen infolge von Probleme mit elektrischen Schaltungen gewährleistet. Schäden, die auf Benutzereingriffe zurückzuführen sind, beispielsweise Demontage, starke Schläge, Eintauchen in Wasser, Verbindung mit dem falschen Strom- oder Spannungskreis oder Schäden infolge von Naturkatastrophen, wie Feuer, Flut oder Erdbeben, sind kein Bestandteil der Garantieleistungen.
2. Verbrauchsmaterialien (wie Fußpedal) und Ersatzteile sind kein Bestandteil der Garantieleistungen.

1

Unterstütztes Betriebssystem

Windows XP/Vista/Win7/Win8/Win10/Win11

Vorstellung der Tastenfunktionen

FN1-Taste gemeinsam mit anderen Tasten

- 1. FN1+<ESC >=
2. FN1+ Umschalten+<ESC >= ~
3. FN1+<1~0) >= F1~F10
4. FN1+<-\_>=F11
5. FN1+<+>=F12
6. FN1+<A>=←
7. FN1+<S>=↓
8. FN1+<D>=→
9. FN1+<W>=↑
10. FN1+<P>=DRUCK
11. FN1+<{>=HOME
12. FN1+<}>=ENDE
13. FN1+<p>=BILD nach Oben
14. FN1+<">=Bild nach Unten
15. FN1+<.>=EINFÜGEN
16. FN1+</?>=LÖSCHEN
17. FN1+WIN: Windows-Taste sperren, zum Entsperren erneut Drücken
18. FN1+ESC: Rücksetzen auf die Werkeinstellungen

FN2-Taste gemeinsam mit anderen Tasten

- 1. FN2+"9" =18 Umschaltbare Hintergrundbeleuchtung

2

- 2. FN2+ "0": Hintergrundbeleuchtung ausschalten
3. FN2+ "-": Helligkeit-, insgesamt 5 Level
4. FN2+ "+": Helligkeit+, insgesamt 5 Level

Anpassung der Hintergrundbeleuchtung für andere Games

- 1. FN2 + „Rücktaste“ drücken: aktiver Hintergrundbeleuchtung-Aufzeichnungsmodus
2. FN2 + „Rücktaste“ erneut drücken: Aufnahme starten, die CAPS-Taste blinkt kurz. Für die Beleuchtung die gewünschte Taste drücken. Zum Speichern und Beenden FN2 + „Rücktaste“ drücken.
3. Angepasste Hintergrundbeleuchtung durch Drücken von FN2 + „Rücktaste“ anzeigen.
4. Angepasste Hintergrundbeleuchtung löschen: FN1+ „Rücktaste“ 5 Sekunden gedrückt halten, um alle angepassten Hintergrundbeleuchtungen zu löschen.

FAQ

- 1. Wenn die Tastatur nicht reagiert, überprüfen Sie bitte, ob die Tastatur korrekt in den entsprechenden USB-Anschluss im Computer eingesteckt ist oder versuchen Sie, die Tastatur an einem anderen USB-Anschluss des Computers anzuschließen.
2. Wenn Sie Flüssigkeit über die Tastatur verschütten, ziehen Sie bitte die Tastatur sofort aus dem Computer, wischen Sie die Flüssigkeit von der Tastatur ab und legen Sie die Tastatur zum Trocknen in die Sonne. Stellen Sie vor dem nächsten Gebrauch sicher, dass die Flüssigkeit in der Tastatur vollständig verdunstet ist.



3



REDRAGON ELISE RAINBOW MECHANICAL GAMING KEYBOARD



Please scan here to download user manual

Mechanical Gaming Keyboard Operating Instructions

Table with 4 columns: 型号 (K615-R/8558), 名称 (说明书), 日期 (2022-7-11), 页码 (1 OF 1), 备注 (尺寸: 100x100mm (折页), 材质: 80g书写纸, 印刷: 单黑色双面印刷), 文件编号, 绘图 (雷国建), 审核, 批准, 版本 (A.0)

