



Change the way you think about time

3D UNLIMITED

INSTRUCTION MANUAL



1. How to read the time

- This watch uses an LCD “always on” display to show the time.
- You can illuminate the display for a short time with the EL backlight by pressing button A.
- The time is displayed digitally on three sides of the cube as shown in the diagrams below.

Hours



Single Minutes



10 Minutes



Example

12:54



2. How to read the date

- Press button B to display the date.
- The date icon indicates that you are in date mode.
- You can illuminate the display for a short time with the EL backlight by pressing button A.
- The date is displayed on three sides of the cube as shown in the diagrams below.
- The display will change back to time mode after a short time.

Month



Date icon

10 Days



Single Days



Example

May 26th



3. How to set the date and time

- Press and hold button B for 3 seconds to enter setting mode.
*Note after 10 seconds of inactivity setting mode will deactivate

I. Setting the year

- The year digits will flash when you are in year setting mode.
- Press button A to increase the year as required.
- Hold button A to increase the years more quickly.
- Press button B to confirm and move to the month.

II. Setting the month

- The month digits will flash when you are in month setting mode.
- Press button A to increase the month as required.
- Hold button A to increase the months more quickly.
- Press button B to confirm and move to the date.

III. Setting the date

- The date digits will flash when you are in date setting mode.
- Press button A to increase the date as required.
- Hold button A to increase the date more quickly.
- Press button B to confirm and move to the hour.

IV. Setting the hour

- The hour digits will flash when you are in hour setting mode.
- The PM icon in setting mode indicates that you are setting the time in PM.
- Press button A to increase the hour as required.
- Hold button A to increase the hours more quickly.
- Press button B to confirm and move to the minutes.

V. Setting the minutes

- The minute digits will flash when you are in minute setting mode.
- Press button A to increase the minutes as required.
- Hold button A to increase the minutes more quickly.
- Press button B to confirm and exit setting mode.

Example

June 24th



Date icon

8:41PM



PM icon (only for setting)

4. User information

I. Battery

- This watch uses an CR2016 replaceable watch battery.
- Battery lifetime will vary depending on use, but is estimated to last for at least one year.
- To maximize battery life you should limit use of the EL backlight.

II. Warranty

- This watch is covered by a 1 year manufacturers' warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

III. Caution

- This watch is water resistant to 3ATM. Please do not use the watch in the shower, for swimming or for other water related activities.

SPECIFICATIONS

Case Materials	Stainless Steel
Strap Materials	Stainless Steel
Case Dimensions	38 x 42 x 8.3 mm
Finish	Polished
Maximum Fit Wrist Size	210mm (approx.)
Weight	120g
Display	Colored LCD with EL Backlight
Battery	CR 2016
Water Resistance	3 ATM

3D UNLIMITED

取り扱い説明書



1. 時刻の読み方

- ・この商品はLCDディスプレイに常時に時刻が表示されます。
- ・Aボタンを押すと数秒間ELバックライトを点灯させることができます。
- ・時刻は下図のように、立方体の3面に沿うようデジタル数字で表示されます。

時



1分単位



10分単位



時刻表示例

12:54



2. 日付の読み方

- ・ Bボタンを押すと日付が表示されます。
- ・ 日付表示の画面ではDATEアイコンが表示されます。
- ・ Aボタンを押すと数秒間ELバックライトを点灯させることができます。
- ・ 日付は下図のように、立方体の3面に沿うようデジタル数字で表示されます。
- ・ 数秒間表示した後、時刻表示に戻ります。

月



DATE アイコン

10日単位



1日単位



日付表示例

5月26日



3. 日付・時刻の設定

- ・ Bボタンを3秒間押し続けると設定モードになります。
※10秒間何も操作をおこなわないと、設定モードは自動的に終了します。

I. 「年」の設定

- ・ 「年」の設定時は、年表示のデジタル数字が点滅します。
- ・ Aボタンで1年ずつ増やすことができます。
- ・ Aボタンを長押しすると連続で年を増やすことができます。
- ・ Bボタンを押すと確定して次の「月」の設定に移動します。

II. 「月」の設定

- ・ 「月」の設定時は、月表示のデジタル数字が点滅します。
- ・ Aボタンでひと月ずつ増やすことができます。
- ・ Aボタンを長押しすると連続で月を増やすことができます。
- ・ Bボタンを押すと確定して次の「日」の設定に移動します。

III. 「日」の設定

- ・ 「日」の設定時は、日表示のデジタル数字が点滅します。
- ・ Aボタンで1日ずつ増やすことができます。
- ・ Aボタンを長押しすると連続で日を増やすことができます。
- ・ Bボタンを押すと確定して次の「時」の設定に移動します。

IV. 「時」の設定

- ・ 「時」の設定時は、時表示のデジタル数字が点滅します。
- ・ PM時間帯の設定時にはPMアイコンが表示されます。
- ・ Aボタンで1時間ずつ増やすことができます。
- ・ Aボタンを長押しすると連続で時間を増やすことができます。
- ・ Bボタンを押すと確定して次の「分」の設定に移動します。

V. 「分」の設定

- ・ 「分」の設定時は、分表示のデジタル数字が点滅します。
- ・ Aボタンで1分ずつ増やすことができます。
- ・ Aボタンを長押しすると連続で分を増やすことができます。
- ・ Bボタンを押すと確定して設定モードは終了します。

表示例

6月24日



DATE アイコン

8:41PM



PM アイコン (設定時のみ表示)

4. インフォメーション

I. バッテリー

- ・本品には交換可能なCR2016リチウムバッテリーが内蔵されています。
- ・バッテリーの寿命は使用状況によって異なりますが、およそ1年間のご使用が可能です。
- ・ELバックライトの使用回数を減らすことで、バッテリーの寿命を長くすることができます。

II. 保証

- ・生産時に生じた不良にのみ1年間の無償修理を保証します。不注意による故障、破損、水没等は保証期間内であっても有償修理となりますので、ご了承ください。

II. ご注意

- ・この商品は3気圧防水(日常生活防水)です。シャワーやスイミングまたは、水を扱う際の使用はお避けください。

商品仕様

ケース素材	ステンレス スチール
ストラップ素材	ステンレス スチール
ケースサイズ	38 x 42 x 8.3 mm
仕上げ	光沢
最大装着 リストサイズ	約210mm
重量	120g
ディスプレイ	ELバックライト付カラーLCD
バッテリー	CR2016
防水性能	3気圧(日常生活防水)

