



Retsuction Manual




Key A - Time Telling Key B - Set Function キーA 時間表示 キーB 時間設定 キーAを押し時間を数秒間表示します。

Press Key A will see the time for a few seconds.

Example 1: 4:35




Example 2: 10:30




How to set the time :



Press Key B, the Hour blink first, press Key A to increase the Hours.



 Press Key B to confirm and move to 10X minute adjustment. Press Key A to increase the digit.




 Press Key B to confirm and move to 1X minute adjustment. Press Key A to increase the digit.
Press Key B to confirm and exit setting.


時間設定の仕方



■ キーBを押し時間LEDを点滅させ、キーAで時間を 設定します。



■ 再度キーBを押し時間設定を確定した後、10分単位LEDを 点滅させます。キーAで10分単位の設定を行います。



■ キーBで設定を確定し、1分単位LEDを点滅させます。 キーAで1分単位の設定を行い、キーBで全ての設定を 決定します。

Battery replacement

- One Lithium battery CR1620 provides the power to operate the lights
- If you notice your watch's light is getting dimmer, this is an indication that your battery needs to be replaced
- Do not wait until your watch stops functioning
- Weak or dead battery left in your product for an extended time may damage the movement
- To avoid the possibility of damaging your product, we recommend that you send it to watch specialist to have the battery replaced and the case back properly sealed

Cautions

- Don't press buttons under water nor with excessive moisture on the product surface.
- Avoid long-term exposure to extreme temperature, direct sunlight. This can cause material coloring to fade or discoloration.
- Please avoid rough use or dropping this product. Do not use strong detergent, sprays or chemicals as this will dis-color the case or strap.
- To clean your watch use only soft cloth, moistened lightly.

電池の交換

CR1620を使用しています。 もし少しでも時計の表示が暗くなった場合 すぐに使用を中止し、電池の交換を行ってください。 弱った電池を使い続けると、中の電子部分が 損傷する可能性があります。 電池の交換は専門の時計店等で行うことを お勧めいたします。

注意

水中や水滴が表面についた状態でボタンを押さないで ください。 高温、面射日光を避けてください。材質が変化する可能性 があります。 商品を落下させたりしないでください。

.