Set up instructions

1 Remove frame and graphic from nylon bag.

2 Ensure "adjustable feet" of frame are on the floor. Pull up display into upright position.

3 Lock all hooks between front and back hubs.

4 Adjust leveling feet for desired angle. Ready pop display can now easily be moved into position.

5 OPTIONAL

Attach lights to top of frame by sliding the plastic "x blocks" under the frames cross sections.

Warning: To avoid damage, separate end caps & disconnect ALL hooks before collapsing the frame.

How to install or replace graphics on your OneFabric:

1 Assemble frame and lay flat on its back. Remove existing graphic.



2 Starting at one corner, attach velcro on the graphic to velcro on the frame.
NOTE: Velcro on the graphic should extend approx. 1/4" - 1/2" beyond velcro on the frame (it should not be flush).

3 Working in a continuous direction around the frame, attach the rest of the graphic. Make sure the graphic is pulled taut while attaching the velcro.

4 If needed, adjust velcro for taut fit.

LAUNCH SUNDAY

Ready pop large straight - RP4X3STR