FOLLOW THE PROCEDURES TO INSTALL AND PLAY YOUR HYPERION® DASH CAMERA

1) Hyperion® dash camera supports up to 64GB MicroSD memory card with a speed rating of class 10, UHS-1 or higher.(1)
2) Ensure that the memory card has been inserted in the correct direction. The metal contacts on the memory card car facing towards the screen of dash camera.(2)

1

2



3) Plug the power cord into the cigarette lighter socket and the dash camera. And remove the protective film from the lens and suction pad.(3)

3



4) Use a pry tool to lift the edges of the windshield trim/molding and tuck in the power cord.(4) Then position the dash camera in the center of your windshield near the top, behind rear-viewer mirror.(5)

4



5



5) Turn on the engine and dash camera will power on and start recording automatically.

6) Please access “Time Settings” on page 1/3 of General Setting on the menu. And adjust the time setting in your dash camera correctly so the time stamp on video reflects recorded time accurately.(6)

6

⚠ **CAUTION**

* In certain vehicles the cigarette port continues to supply power even when the vehicle's ignition is turned off.
  In this case, please disconnect the dash camera to prevent the vehicles battery from draining.

115mm

ADAS CALIBRATION

Access “ADAS Calibration” on page 3/3 of General Setting on the menu. Use "ADAS calibration" to adjust your dash camera and make sure it is positioned correctly.

RED horizontal line should align with the tip of engine hood on the camera screen.

BLUE vertical line should align with the middle of engine hood on the camera screen.



QUICK BUTTONS

The buttons on this dash camera sends different commands when the dash camera is in different working modes such as recording mode or general setting mode.

◆ Recording Mode (Default mode when dash camera is powered on)

- Lock or unlock the current video file.
- Turn on or turn off to record sound while in recording.
- Stop recording. (Switch to standby mode)



- Press rapidly to turn off the screen while dash camera continues to record. Press rapidly again to turn it on. Press and hold to turn off the dash camera.

◆ Standby Mode (Camera is not recording)

- Press to switch between Standby mode / Snapshot mode / Video replay / Snapshot replay.
- Enter the menu. (Switch to setting mode)
- Turn on or turn off to record sound while in recording.
- Start recording. (Switch to recording mode)

- Press rapidly to enter sleep mode. Press rapidly again to wake up. Press and hold to turn off the dash camera.

◆ Snapshot Mode (Camera is not recording)

- Press to switch between Standby mode / Snapshot mode / Video replay / Snapshot replay.
- Enter the menu. (Switch to setting mode)
- Take photo.

- Press rapidly to enter sleep mode. Press rapidly again to wake up. Press and hold to turn off the dash camera.

◆ Snapshot Replay and Video Replay (Camera is not recording)

- Press to switch between Standby mode / Snapshot mode / Video replay / Snapshot replay.
- Enter the replay setting.
- Select the previous file.
- Select the next file.
- Play and pause. (Press to return to playlist)



- Press rapidly to enter sleep mode. Press rapidly again to wake up. Press and hold to turn off the dash camera.

◆ Setting Mode (Camera is not recording)

- Press to switch to next page.
- Enter or exit the menu.
- Up
- Down
- Select



- Press rapidly to enter sleep mode. Press rapidly again to wake up. Press and hold to turn off the dash camera.

240mm

展开240*115mm

158G 铜版纸2面印覆光膜-两折

PANTONE 150 C