LED MUSIC THERMOSTATIC SHOWER
INSTALLATION GUIDE

B-6

INSTALLATION CONDITION

1.Refer to the《Standard Part List》when unpacking , check all parts available .



2.Do not disassemble mixer body by yourself.

3.Connect inlet hoses to supply valves.



4.Make sure inlet pipes and supply valves have been installed and cleaned, also ensure no impurities in pipeline.

5.After installation , check all joints for leakages.

6.Suggest don't fit the faucet in the severely corrosive environments.

YOU MAY NEED:



Tone optical acoustic controller


Waterfall X2
Music X2
LED X2
Rain X1
1
9
4
5
27
6
7
8
2
3
10
11
12
14
15
16
17
18
13
19
20
21
22
23
24
26
25
28
29

No.	Part name	Qty	No.	Part name	Qty	No.	Part name	Qty
1	Shower head body	1	11	Holder cup	1	21	Valve gasket spare parts	6
2	Corrugated pipe	2	12	Hand shower holder	1	22	Handle cup	1
3	Water proof power supply	1	13	Shower hose	1	23	Handle screw	1
4	Shower head screw	8	14	Main body	1	24	Handle Wrench	1
5	Shower head wrench	1	15	Panel	1	25	Holder Wrench	1
6	Controller	1	16	Water diverter rod	4	26	Holder spare O-ring	1
7	Wifi controller	1	17	Water diverter	4	27	Controller pedestal	1
8	Wifi controller tape	1	18	Handle	1	28	Instruction manual	1
9	Spare rubber washer	2	19	Body jet cup	6	29	Gloves	2
10	Shower hand	1	20	Body jet	6			

◆ INSTALLATION SHOWER SET SIZE & WATER PIPE LINE REFERENCE

Step 1

Unit: mm/inch


Over Head shower
5 33/64"-6 19/64"
(140-160mm)
Hand shower
11 13/16"-15 47/64"
(300-400mm)
47 1/4"-59"
(1200-1500mm)
43 5/16"-51 3/16"
(1100-1300mm)
7 7/8"-9 13/16"
(200-250mm)
HOT
COLD
Hot water inlet
Cold water inlet
Finish surface

Please refer to above for height dimensions of shower installation.

Step 2

Unit: mm/inch


Over Head shower
5 33/64"-6 19/64"
(140-160mm)
Hand shower
11 13/16"-15 47/64"
(300-400mm)
47 1/4"-59"
(1200-1500mm)
43 5/16"-51 3/16"
(1100-1300mm)
7 7/8"-9 13/16"
(200-250mm)
HOT
COLD
Hot water inlet
Cold water inlet
Finish surface

Please refer to above for height dimensions of shower installation.

◆ INSTALLATION DEPTH OF MAIN BODY

Unit: mm/inch


130mm
5 1/8"
463mm
18 1/4"
Hot water inler
Cold water inler
90mm*418mm
3 17/32-16 29/64"
Hole size
Tile wall
Depth
80mm*95mm
3 1/8-3 3/4"
The depth of main body should be in the thickness range of wall tile

1: Including the thickness of ceramic tile is less than or equal to the thickness of valve 3 3/4"(95mm), so the thickness of tile must be calculated before installation.
2: Installation Main body depth not less than 3 1/8"(80mm)min and not more than 3 3/4" (95mm) Max. Otherwise, the panel cannot be installed.
3: The hole size of the main body after tiling is smaller than the size of the panel.

◆ WALL MOUNTED/CELILING MOUNTED INSTALLATION BEFORE TILONG


Recommend using copper drop ear pipe elbow(NPT1/2")

1:Recommend using Copper drop ear pipe elbow(NPT 1/2)
USA:1/14 NPT 2 -Canada:1/2"-14 NPT Europe:G1/2"

◆ INSTALLATION DEPTH OF SHOWER ARM &SHOWER HOLDER & BODY JET


Over Head shower
Tile wall
USA: 1/2"-14 NPT
Canada: 1/2"-14 NPT
Europe: G1/2"
15mm
19/32"
Face of plasterguard should be flush with finish wall line
USA: 1/2"-14 NPT
Canada: 1/2"-14 NPT
Europe: G1/2"
15mm
19/32"

The installation depth of shower arm &shower holder &body jet can't over 19/32"(15mm)so the thickness of tile must be calculated before installation.

MAIN BODY CONNECTING PIPE SCHEMATIC DIAGRAM

Warning:must install hot water and cold water inlet strictly as instructions.


Wrap enough teflon tape
Level
Mixed water outlet pipe
Mixed water outlet pipe
Mixed water outlet pipe
Mixed water outlet pipe
USA: 1/2"-14 NPT
Canada: 1/2"-14 NPT
Europe: G1/2"
Hot water pipe
Cold water pipe

1. As shown in the figure, the inlet and outlet pipes are pre-buried,pay attention to the correct direction of installing the pre-buried main body,and make sure that the mark level on the top of the installation box is facing upward.
2. Install the hot and cold water inlet pipes,Shower head and hand shower holder body jet pipes. Turn on the water source to test whether the left and right inlet pipes are tightly connected without leakage.After the test,adjust the flow switch to be on to test whether the mixed outlet pipe.The connection is tight and there is no leakage.

MAIN BODY VALVE INSTALLATION


14
15
16
17
18
23
22
21

Use ㉑ Valve gasket spare parts and to fixed ⑭ Main body on the wall and then install ⑮ Panel ⑱ Hand㉒ Hand cup and ㉓ Hand screw ⑰ Water diverterl ⑯ Water diverterl rod in the correct order.

Shower head power/water pipe-layout


G1/2 or NPT1/2
Outside Thread
Multi-socket
110-220V 50/60Hz
Inner rain
Waterfall
Spray

Install the power switch in the appropriate position by yourself Water pipes should be arranged according to the showerhead function

Shower head, two inlet pipes
need to be laid out, Waterfall and Inner rain;

Shower head holes on ceiling


inside size
inside size

Shower head
Shower hole inside size 535x335mm
21 1/16"-13 3/16"

Shower head intelligent exploded view


① LED Power Supply
Transfomer input100~240V 50/60Hz
Output 12/5A IP67
② Stainless steel fix frame
③ Wifi receiver connector
④ Shower head
⑤ Shower fixing screws
⑥ Decorative shower panel
⑦ Decorative screws

Respectively to unscrew ⑦Decorative screws, separate ⑥Decorative shower panel and ④Shower head; Respectively to unscrew ⑤Shower fixing screws, separate ④Shower head and②Stainless steel fix frame.

Shower head installation fixed frame A:


Fix frame is horizontal with ceiling
Fix frame
wood screw

Shower head installation fixed frame B:


Expansion bolts 150-500
5 7/8"-19 3/4"
Fix frame
Fix frame is horizontal

There are two methods to fix ②Stainless steel fix frame.
A: Use screws to fix directly;
B: Use of expansion bolts150-500mm5 7/8"-19 3/4".

Layout for power


Multi-socket
110-220V 50/60Hz
Transfomer input
100~240V 50/60Hz
Output 12/5A IP67
①
Fix frame
⑨
⑧
Receiver
③
LED (signal line)
LED (input)
WiFi Controller

Connect①LED Power Supply with ③WiFi Receiver Connector and⑧Showe Music Connector respectively; ⑧The Showe music connector has two connectors. If you have only one music, only one needs to be connected and the other one does not need to be connected. Finally, connect the male connector of ③ WiFi receiver with the female connector of ⑨Shower head LED input. (Attention: the male connector is matched to the female connector each other, do not connect wrongly, otherwise it will cause damage to the receiver).

Layout for water pipe


⑩
Fix frame
LED(signal line)
Hose
Hose
PPR-25
USA: 1/2"-14 NPT
Canada: 1/2"-14 NPT
Europe: G1/2"

Connect one end of the three⑩corrugated pipes with the embedded PPR water pipe respectively, the other end connect with the three water

Install Shower


② Fix frame
Shower
buckle up
⑪

Hook⑪Wires with a hook on ②Stainless steel fix frame, used to assist in easy installation of showerhead;

Connect the water inlet pipe


Corrugated pipe
Shower
Corrugated pipe
Water inlet of shower

Connect LED(signal line)


Corrugated pipe
Shower
Receiver
LED(signal line)
LED(Input)
WiFi Controller

Testing the water


Corrugated pipe
Shower
Testing the water

Shower installation


Corrugated pipe
④
Shower
⑤
Fixing screws of shower

⑤Shower fixing screws are fitted with④ Shower head.

Fix the decorative panel of shower


Shower
⑥Decorative panel of shower
⑦Decorative screws

⑦Decorative screws are fitted with⑥ Decorative shower panel.

Touch remote use instruction:

Main parameter:
Panel controller:
Working Temp.:-20~60
Supply Voltage:DC12-24V
Size:L50*W35*H23mm
1 15/16"*1 6/16"*14/16"
Output:3Channel
Output Current:<2A(each channel)
Connection mode:common anode
Touch Remote:
Working voltage:1.5V*3V
Emission current:10mA
Working Current:300uA
Standby Current:3uA
Standby time:6 mouths
Control distanceL20M
Color pulley point:60

CONTROLLER
CE RoHS
M+
M-
B+
S-
S+
B-

1.Touch remote have 64 touch key,each keys function below:


1
5
2
6
3
7
4
8
9
M+
M-
B+
S+
S-
B-

① Turn ON/OFF
⑤ Mode Switch
② Color Touch Ring
③/⑥ Color Temperature adjusting
④/⑧ Dynamic Speed adjusting
⑦/⑨ Dynamic Brightness adjusting

Pause:on the dynamic mode,you can make the controller to stop the current state now.

2.Power supply management:

Stop to use the remote more than 20s,the remote will enter the stand by state(untouchable state): slightly shake once,then the remote will come back to the normal working state(touchable state)

3.Indicator light instrction:

Slightly shake once,then the remote will come back to the normal working state(touchable state)

3.1.The remote is idle or sent signal when the PWR bright,PWR is off,then means the remote is in standby state;

3.2.RF is bright,that means remte is senting signal.off means there is no signal sending

USER MANUAL

Mode:

NO.	FUNCTION	REMOTE
1	Static red	Brightness is adjustable Speed is unadjustable
2	Static green	
3	Static blue	
4	Static purple	
5	Static blue-green	
6	Static yellow	
7	Static white	
8	R G B Jumping	Brightness is adjustable Speed is adjustable
9	R G B Gradual	
10	7-Colors Jumping	
11	7-Colors Gradual	

Controller connections shown:


M+
M-
B+
S+
S-
B-
LED controller

Remarks:

1. This product should be commissioned and installed by qualified personnel.
2. This product can not be waterproof,need to avoid sun and rain,if installed outdoors, please use waterproof box.
3. Good heat dissipation conditions will extend the life of the LED controller,please install the product in a well-ventilated environment.
4. Please do not install or use such products in lightning,thunder,strong magnetic or high voltage applications.
5. Please check whether the output voltage of the LED power supply used meets the product voltage range requirements.
6. The diameter of the wire used must be sufficient to load the connected LED luminaire,and ensure that the wiring is firm,to avoid the wire overheating or poor contact triggers the accident.
7. Before power-on debugging,ensure that all wiring is correct to avoid damage to the luminaire due to wiring errors.

Body jet installation


Step 2
Step 1
G1/2
Step 3
Step 2
Step 1
NPT1/2
G1/2

Step 1.Wrap the threaded pipe of NPT1/2 with Teflon tape and screw it into the wall.
Step 2.Cut off excess part with a saw.
Step 3.Put on the decoration cap，then screw the massage shower in.

Install the hand shower holder


Step 3
Step 2
Step 1
Step 4

Step1.Screw the thread into the water pipe inside the wall.
Step2.Screw the main body into the thread.
Step3.Rotate and fix the body with the special-shaped wrench.
Step4.Connect hand shower and the hose.

Care and Maintenance

In order to keep the mixer surface bright , please clean the mixer regularly.

Rinse faucet with clean water and wipe with soft cotton cloth.


Polishing Powder
Cleaning Powder

Avoid suing cleaning powder , harsh cleaning chemicals, brushes,and cloth with coarse surface to prevent scratching and corrosion.



Do not use acid cleaner to clean the faucet as it may cause surface corrosion of the faucet. If the faucet comes into contact with harmful acid substances, please rinse it with water immediately.

If a large-scale clean-up is necessary, follow these procedures:

1:Use clean water and soft cloth to remove dirt on the surface as much as possible.

2:Use one of the following cleaners to remove dirt on the surface

Mild liquid cleaner.

Colorless glass cleaner, powder cleaner which does not have abrasive function and can be dissolved completely.

Polish liquid which does not abrasive function.

3:After cleaning, remove the cleansing agent with clean water completely and wipe with soft cotton cloth.