英文

100.00 mm

55.00 mm

LEKATO

Loop Auto

Owner`s Manual

取扱説明書

✉ support@lekatodeal.com

● www.lekatodeal.com

EN

Warranty
Thank you for choosing lekato products.
Please read this manual carefully and keep it for further reference, if there's any questions regarding to this product, please feel free to contact us

✉ support@lekatodeal.com
● www.lekatodeal.com

日文

100.00 mm

55.00 mm

LEKATO

Loop Auto

Owner`s Manual

取扱説明書

✉ support@lekatodeal.com

● www.lekatodeal.com

JP

Lekato製品をお選びいただきありがとうございます。
このマニュアルを注意深く読み、後で参照できるように安全な場所に保管してください。
この商品についてご不明な点がございましたら、お気軽にお問い合わせください。

✉ support@lekatodeal.com
● www.lekatodeal.com

Preface

Thank you for purchasing the LOOP AUTO guitar effect pedal. In order to let you easily experience the product, we are equipped with a detailed user manual, from which you can get the introduction of the product and the knowledge of how to use it.

Attentions

The power supply

Please ensure that the maximum operating voltage of 9V(10%)power transformer with negative inside and positive outside is not more than 10V.otherwise it may cause equipment damage. Please unplug the power when you don't need to use this product or in thunderstorm weather.

The connection

Radio, television and other electromagnetic waves may cause interference to the use of equipment, so please try to stay away from radio and television and other equipment.

Place placed

To prevent deformation, discoloration and other damage to the product, please avoid the following situations:

■Direct sunlight ■Heat source ■Magnetic field

■High temperature or moist district ■High humidity ■Strong oscillation ■Shaking

---

Main Features

This product is exquisitely designed but powerful! It not only improves the playability of music, but also allows you to get unlimited creative inspiration!

1. Phrase infinite loop playback
2. Real-time control of playback volume
3. Total of three LOOP phrases can be recorded
4. The total recording time is up to 18'36''
6. Each loop phrase supports unlimited superimposed audio track recording function
7. Achieve seamless switching playback/recording of the previous song/next song phrase
8. SYNC, precise signal induction synchronous recording function
9. Single footswitch controls: record, playback, overdub, undo, redo, stop, delete.
10. It can be connected to the LEKATO Wireless Turner, which is more convenient to control, allowing you to easily complete the performance
11. Built-in high sensitivity tuning function
12. Support import/export WAV audio files
13. LED high-definition screen display
14. Using 9V DC power adapter (⊖→⊕)

Control Panel

①. Power jack: Use a standard 9V DC power adapter(⊖→⊕).

②. LED display: Real-time display of the status and progress of each function mode.

③. LEVEL knob: LOOP playback volume control, when it is turned to the 12 o'clock position, the playback volume and instrument input volume are 1:1, turn counterclockwise to turn down the playback volume, and turn clockwise to turn on the playback volume.

④. Output jack:1/4 mono audio jack, outputs the signal.

⑤. Progress Bar: Real-time display the progress of the recording / playback.

⑥. Footswitch: Control recording, playback, overdub, undo, redo ,and delete.

⑦. USB jack: External Wireless Turner port, import/export internal WAV file data port, hardware upgrade port.

⑧. Button: Short press to the next song, long press for 1s to enter the "SYNC recording" mode, long press for 3s to enter the TUNER mode.

⑨. "#"Light: In the recording mode, it is the 'SYNC Recording' function prompt; in the tuning mode, it is the "#" indicator of the pitch names.

⑩. Number: The number of the song in the recording mode, and the pitch name in the tuning mode.

⑪. Input jack: 1/4 mono audio jack, for connecting guitar.

⑫. Tuning display bar: In tuning mode, it is the tuning table.

序文

LOOP AUTO フレーズループレコーダー/プレーヤーをご利用いただきありがとうございます。製品を簡単に体験できるように、製品の紹介や使用方法などの知識が得られる詳細な取扱説明書を用意しています。

注意事項

電源を供給する

必ず内部がマイナス、外部がプラスの9V（10%）電源トランスを使用してください。最大動作電圧は10Vを超えてはなりません。超えない場合、機器が損傷する可能性があります。本製品を使用する必要がない場合や雷雨の場合は、電源ボタンを押してください。

接続

エフェクターが機器に接続または切断されている場合は、必ず電源およびその他の関連機器の電源を切ってください。これにより、機器の故障や他の機器の損傷を防ぐことができます。

配置場所

製品の変形、変色、その他の損傷を防ぐために、次の条件を避けてください;

■直射日光 ■熱源 ■磁界 ■高温多湿

■ほこりや不潔な場所 ■より高い温度 ■強い衝撃や揺れ

LOOP AUTOのパフォーマンスの概要

この製品は絶妙に設計されていますが、強力です！音楽の演奏性を向上させるだけでなく、無限の創造的なインスピレーションを得ることができます！

1.フレーズ無限ループ再生
2.再生音量のリアルタイム制御
3.合計3つのLOOPフレーズを録音できます
4.各ループフレーズの録音時間は最大372秒です
5.合計録音時間は最大18分36秒です
6.各ループフレーズは無制限のスーパーインポーズオーディオトラック録音機能をサポートします
7.前の曲/次の曲のフレーズのシームレスな切り替え再生/録音を実現します
8.SYNC信号誘導同期記録機能
9.シングルステップネイルは、録音、再生、オーバーレイ録音、最後のオーバーレイトラックの、削除されたトラックの復元などを制御します。
10.操作が便利なLEKATO拡張ペダルに接続できるので、簡単に演奏が完了します。
11.内蔵の高感度チューニングテーブル
12.WAVオーディオファイルのインポート/エクスポートをサポートします
13.LED高解像度画面ディスプレイ
14.ユニバーサル9V（外部正および内部負）モノブロック効果電源
15.外観はコンパクトで持ち運びが簡単です

LOOP AUTOパネルの説明と紹介

①電源ソケット：標準の9V（外部プラスおよび内部マイナス）電源アダプターを接続してください。

②表示画面：各機能モードの状態と進行状況をリアルタイムで表示します。

③LEVELつまみ：LOOP再生音量コントロールボタン12時の位置に回すと、再生音量と楽器入力音量が1：1になります。反時計回りに回すと再生音量がオフになり、時計回りに回すとオンになります。再生音量。

④1/4オーディオ出力インターフェース：スピーカーアンプ機器に接続された6.35mmオーディオインターフェース。

⑤録音/再生進行状況表示バー：録音/再生の進行状況をリアルタイムで表示します。

⑥多機能ステッピングネイル：LOOPの録音、再生、削除、復元の機能を制御します。

⑦USBデータインターフェース：外部拡張ペダルインターフェース、内部WAVファイルデータポートのインポート/エクスポート、ハードウェアアップグレードポート。

⑧多機能ボタン：1回短く押すとループ内の次の曲に切り替わり、1秒間長押しすると「同期録音」モードになり、3秒間長押しするとチューナーモードになります。

⑨同期録音プロンプトライト/「#」立ち上がり記号：録音モードで点灯している場合は「同期録音」機能のプロンプトライト、チューニングモードでは表示されているサウンド名の#インジケーターです。

⑩デジタル表示エリア：録音モードでは曲番号が表示され、チューニングモードではリアルタイムのピッチ名が表示されます。

⑪ 1/4オーディオ入力ジャック：楽器、6.35mmオーディオ入力インターフェース。

⑫チューニング表示バー：チューニングモードでは、チューニングテーブルです。





Connection Method



Amplifier ← LOOP AUTO ← Guitar

Quick Guide

①Recording

1、Plug in the power supply, the LED full-screen light quickly turns on and then goes out, the screen displays the track '1':
  1) Have recording data, screen lights up with a blue circle light;
  2) No recording data, only the LOOP number is displayed.

2、When there is no recording data, step on the footswitch once, and the screen will display track '1'. At this time, the first loop will start recording, and the progress bar will display red and will extend corresponding to the recording duration. The max recording time is 372s.



②Stopping/Starting LOOP Playback&Overdub

1、During playback, step on the footswitch twice to stop playback. At this time, the progress bar lights up a full circle of blue lights, indicating that there is audio stored in the track '1'.

2、In the stopped state, press the footswitch once to play.





3. During playback,step on the footswitch to enter the dubbing state. After the dubbing is completed, it will automatically enter the playing state,and the newly overdub recording will be played at the same time as the original recording. Then step on the footswitch and enter the dubbing state again.Repeated practice leads to unlimited dubbing.The circle lights is red when dubbing and turns blue when playing.





LOOP AUTOの使い方



スピーカーアンプ ← LOOP AUTO ← 楽器音源

LOOP AUTOクイックガイド

①録音

1.9V電源をオンにすると、LEDフルスクリーンライトがすばやく点灯してから消え、画面にトラック「1」がデジタル表示されます。
  (1)記録データがある場合、画面は青い丸ライトで点灯します。
  (2)記録データがない場合は、現在のLOOP番号のみが画面に表示されます。

2.録音データがない場合は、多機能ペダルを1回踏むと、現在のループ番号「1」が画面に表示されます。このとき、最初のループが録音を開始し、プログレスバーが表示されます。赤。長さ372秒。



②停止/スーパーインポーズ

1.ループソングの再生中に、多機能ペダルを2回踏んで再生を停止します。このとき、プログレスバーが青いライトで一周し、現在のループソングに音声が保存されていることを示します。

2.停止状態で、多機能ペダルを1回踏んで演奏します。





3.再生中に多機能ペダルを1回踏むと、スーパーインポーズされた録音状態になり、再生を開始できます。もう一度マルチファンクションペダルを踏むと、スーパーインポーズが終了すると自動的に再生状態になり、新たにスーパーインポーズされた録音が元の録音と同時に再生されます。多機能ステッピングネイルをもう一度踏むと、スーパーインポーズの回数を制限することなく、再びスーパーインポーズの状態になります。


再生
多機能ステッピングネイルを一度踏む
再生
重ね合わせる
多機能ペダルを2回続けて踏む
やめる

③Undo/Redo a overdub

1、Undo-During Loop playback, hold the footswitch for 2s to undo the last overdub(remove the last take),the circle lights will flash in red and then returns to blue.

2、Redo-Hold the footswitch for 2s during Loop playback the circle lights will fash in red and then returns to blue. Then the previous overdub(restored the last take) will be restored.

3、The Undo/Redo function can only be initiated while a loop is playing back, cannot be performed during overdub, recording or stop modes.





④Clear record

All recordings can be cleared by stepping on the footswitch in the stopped state for more than 2 seconds.

Note: If the power is cut off during use, LOOP AUTO will automatically store the data that have been finished, and the data that have not been finished will not be stored. 'Undo/Redo' function can only be operated before the power is off , after the power off, only all the data of the audio tracks can be deleted. When the device is turned on for the second time, if there is no data stored on the device, the screen only displays the track number, and the circle lights will be off. If there have data stored on the device, the screen will displays the loop number, and a full circle of blue lights up, indicating that there are audio files stored in the device, and you can play, overdub, undo, redo, and delete.

LOOP Select

1. At rest
   When LOOP AUTO is turned on, the screen displays the LOOP track number '1'. LOOP track number '1' refers to the first track, you can switch to the next track LOOP 2, LOOP 3 by pressing the button.

2. When playing
   Loop number can be switched to the previous or next song during playback. After the current audio is played to the end, it will automatically switch to the selected track and play.

3.During recording
   Can not select the other loop



SYNC Mode

Synchronous Recording Function

Press and hold the button for 1s, a red ligh
of the digital display area, indicating tha
mode. When the recording is terminated,
"SYNC" mode. You can also exit the "SY
holding the button again for 1s.



In the mode of playback or stop, you can start
During playback, you can select tracks after tu
You also can select any track for 'SYNC'. At thi

---

③元に戻す/復元

1.元に戻す-トラックの再生中に、多機能ペダルを2秒間押すと、プログレスバーが短時間赤く点灯してから、青のライトに戻ります。この時点で、最後に録音されたオーディオトラックが削除されました。

2.再開-トラックの再生中に多機能ペダルを2秒間押し続けると、プログレスバーが一時的に赤く点灯し、青のライトに戻ります。この時点で、で削除された最後のスーパーインポーズされたトラックは前のステップが復元されました。

3.元に戻す操作と復元操作は、同じトラックで録音を再生している状態でのみ実行でき、録音、スーパーインポーズ、再生停止の状態では実行できません。




再生
多機能ペダルを2回続けて踏む
やめる
ロングステップ多機能ステッピングネイル
削除

④削除

録音を停止すると、多機能ペダルを長く踏むと、フレーズ内のすべてのトラックが完全に削除され、プログレスバーが短時間青色に点灯してから消えます。

注：使用中に電源が切断（シャットダウン）された場合、ホストは録音されたオーディオトラックを自動的に保存しますが、録音されていないオーディオトラックは保存されません。「最後に録音したオーディオトラックを削除/復元する」この機能は、電源を切る前（電源を切る）にのみ操作でき、電源を切った後は、現在の曲のすべてのオーディオトラックのみを削除できます。2回目の起動時にソングの位置にオーディが保存されていない場合は、現在のループのシーケンス番号のみがディスプレイに表示され、プログレスバーがオフになります。現在のLOOPトラックにオーディオデータが保存されている場合は、ソング番号が表示され、プログレスバーがオフになります。現在のLOOPトラックにすでにオーディオデータが保存されている場合は、曲番号がディスプレイに表示され、番号の周りに青いライトが一周して、現在の曲の位置にオーディオファイルが保存されていることを示します。、現在のオーディオを再生し、録音したオーディオを重ね合わせることができます。トラックを追跡または削除します。

ループ切り替え

1.安静時の切り替え
   LOOP AUTOをオンにすると、画面にLOOPトラック番号「1」が表示され、LOOPトラック番号「1」は最初のトラックを示します。で多機能ボタンを押すと、次のトラックLOOP2、LOOP3に切り替えることができます。画面の上部。

2.再生中の切り替え
   ループソングは、再生中に前のソングまたは次のソングに切り替えることができます。現在のソングが再生されると、切り替えられたソングに自動的にジャンプして再生されます。切り替えたトラックに録音ファイルがない場合は、再生を停止してください。

3.録音中に切り替えることはできません。



同期録音モード

同期録音機能の概要

多機能ボタンを1秒間押し続けると、ディスプ
に赤いライトが点灯し、「同期録音」モードに
は、音声信号の入力があることを検出すると、
モードを自動的に開始し、「録音」モードを自


LOOPトラックにオーディオが保存されていない場合
オーディオがLOOPトラックに事前に保存されている場合
ループソングの再生中
同期録音を有効に
た後、ホストがオー
ディオ信号入力を
出したとき

LOOPは、再生または停止の状態でいつでも同
再生中は、「同期録音」機能をオンにした後、
同期録音するトラックを選択できます。このと
たトラックにのみ影響します。

t will light up at the top right
t it has entered the "SYNC"
 it will automatically exit the
NC" mode by pressing and


Press and hold for 1s to enter SYNC mode

This lights up after entering the mode

Automatically start recording,after step on the footswitch once, device immediately enters the playback mode
Automatically play original audio and enter overdub recording mode at the same time
Immediately start the overdub recording mode, and you can choose any time point in the track to overdub on

'SYNC' at any time.
rning on the 'SYNC' function.
s time, 'SYNC' only affects the last track.

Tuner Function

- When you plucked instruments machine starts to receive the sound signal, the screen shows the pitch name of the current input audio signal.
- During tuning, if a red light is on at the top right of the pitch name(as shown on the right#), it means that the pitch has been higher than the semitone of the currently displayed pitch name. If there is no red light on, it means it is within the pitch range.
- Below the pitch name display area is the tuning table, which is composed of five lights. When the red light on the left is on, it means that the current pitch is low. When the red light on the right is on, it means that the current pitch is high. When the middle blue light is on, it means that the current pitch is in tune.
- After the tuning is finished, please short press the button to exit the tuning mode, or you can also choose to step on the footswitch to exit he tuning mode.

Press and hold for 3s to enter the tuning mode(Two '- -' red lights light up in the middle of the digital display, indicating that no sound signal input has been detected.)



Real-time display of the pitch names

Pitch name # sign, for example, the pitch name displayed now is A#

USB Connector

We have set up a Micro USB2.0 data interface for LOOP AUTO. You can use this interface to export/import WAV audio files, or you can connect with a LEKATO Wireless Turner, which makes the operation more convenient.

●Export/import WAV audio files: Please use the USB2.0 data cable included in the package to connect the device to the computer. (When LOOP AUTO is connected to the computer,9V power supply is not required. The computer's USB port is enough. If the computer port's power supply is insufficient, you need to plug in the 9V power supply. The LOOP AUTO screen will light up with the letter 'U', indicating that the connection is successful.)

▲TIPS: If you want to use it on MAC device, please go to our official website to download the LOOP AUTO Driver (Mac), or contact us for help.




AutoPlay
LOOPER
Always do this for this device:
Device options
Sync digital media files to this device
using Windows Media Player
Open device to view files
using Windows Explorer
Import pictures and videos
using Windows
View more AutoPlay options in Control Panel
Portable Devices (1)
LOOPER
Portable Device

When LOOP AUTO is successfully connected to the computer, the computer display will automatically pop out of the internal memory interface of LOOP AUTO, and we can directly click "Open the device and view the file" to enter the internal view. If the internal memory of LOOP AUTO is empty, there is no content in the folder. If there are songs stored in LOOP AUTO, the folder will automatically generate 1.WAV, 2.WAV or 3.WAV files. The file name corresponds to the loop number of the machine. You can export/import these files.
When importing audio, the file format must be a WAV file with 48K/24-bit sampling rate, and the location of the imported song, please change the file name of the WAV file to be imported to the location you want to import the specified song.
Please refer to the figure below:

1.WAV Wave Sound 506KB	2.WAV Wave Sound 557KB	3.WAV Wave Sound 974KB

レイのデジタル表示領域の右上
に入ったことを示します。ホスト
 録音/スーパーインポーズ録音
動的に終了します。


同期録音モードに入るには、1秒間押し続けます

モードに入るとインジケーターが点灯しますンジケーターが点灯します

し
ー
换

記録モードはすぐに自動的に起動します。記録終了後、ステッピングネイルが記録を終了すると、本体はすぐにループ再生モードになります。
元のオーディオをすぐに自動的に再生し、オーバーレイ録音モードも開始します。
すぐにスーパーインポーズオーディオモードをアクティブにすると、曲のどこにでもスーパーインポーズ録音を実行するように選択できます。

期記録を開始できます。
トラックを切り替えることができます。
き、同期録音は現在のトラックには影響せず、最後に選択し

チューニング機能

●楽器を演奏すると、本体が音声信号の受信を開始し、画面中央に現在入力されている音声信号のピッチ名が表示されます。

●チューニングの過程で、画面の右上に赤い点が付いた音名（右側に＃で表示）が表示されている場合は、現在表示されている音名の半音よりもピッチが高いことを意味します。表示されているノート名の右側が点灯していない赤いライトは、現在のピッチが表示されているノート名のピッチ範囲内にあることを示します。

●ピッチ名表示エリアの真下にピッチメーターがあります。ピッチマークは、中央の青色のライトを基にした5つの水平ライトで構成されています。左側の赤色のライトが点灯している場合は、現在のピッチが表示されているピッチ名のピッチ右側の赤いライトが点灯している場合は、現在のピッチが表示されているノート名のピッチよりも高いことを意味し、真ん中の青いライトが点灯している場合は、現在のピッチを意味します。表示されているノート名のピッチに近いです。

●チューニングが終了したら、多機能ボタンを短く押してチューニングモードを終了するか、ファンクションペダルを踏んでチューニングモードを終了するかを選択してください。

按住3秒进入调音模式（显示屏数字显示器中间亮起两个 '- -' 红灯，表示尚未检测到有声音信号输入。）



实时显示当前音高的音名

音名#号标记，例如现在显示的音名为A#

USBデータインターフェース

LOOP AUTO用にMicro USB2.0データインターフェースを設定しました。このインターフェースを使用してデバイス内のWAVオーディオファイルをエクスポート/インポートしたり、このインターフェースを使用して拡張ペダルを接続したりできるため、操作がより便利で簡単になります。パフォーマンスを完了するために。

●WAVオーディオファイルのエクスポート/インポート：LOOP AUTOホストパッケージ1に含まれているUSB2.0データケーブルを使用して、LOOP AUTOホストをコンピューターに接続してください。（LOOP AUTOホストがコンピューターに接続されている場合、LOOP AUTOホストは必要ありません。9V電源、パソコンのUSBポート電源で十分です。パソコンポートの電源が足りない場合は、LOOP AUTOホストを9V電源に接続する必要があります。LOOP AUTOホストをパソコンに接続し、電源が正常である場合、LOOP AUTOホスト画面が文字「U」で点灯し、接続が成功したことを示します。）

▲ヒント: MAC デバイスで使用する場合は、公式サイトから LOOP AUTO ドライバー (Mac) をダウンロードするか、お問い合わせください。




AutoPlay
LOOPER
Always do this for this device:
Device options
Sync digital media files to this device
using Windows Media Player
Open device to view files
using Windows Explorer
Import pictures and videos
using Windows
View more AutoPlay options in Control Panel
Portable Devices (1)
LOOPER
Portable Device

LOOP AUTOがコンピューターに正常に接続されると、コンピューターのディスプレイがLOOP AUTO内部ストレージインターフェイスから自動的に飛び出します。LOOP AUTOメモリストレージの場合は、[デバイスを開いてファイルを表示する]を直接クリックして内部ビューに入ることができます。が空の場合、LOOPの曲番号が対応している場合、フォルダにはコンテンツがありません。これらのファイルをエクスポート/インポートできます。オーディオをインポートする場合、ファイル形式は48k / 24ビットのサンプリングレートのWAVファイルである必要があり、インポートする曲の場所は、インポートするWAVファイルのファイル名をに変更してください。指定した曲をインポートしたい場所シリアル番号で十分です。
以下を参照してください：

1.WAV 波の音 506KB	2.WAV 波の音 557KB	3.WAV 波の音 974KB

LOOP
版本
排版
材质
审核

●Connect with LEKATO Wireless Turner: you can use USB 2.0 cable to connect LEKATO Wireless Turner and LOOP AUTO, this Turner can help you use LOOP AUTO more conveniently. When LOOP AUTO is connected to the LEKATO expansion pedal, the expansion pedal does not need to be turned on (the power switch), just plug and play.

①Short press Turner's left footswitch: switch to the previous song; Short press Turner's right footswitch：switch to the next song.

②Long press the left footswitch or right footswitch of Turner for 1s to enter the "synchronous recording" mode, and press and hold for 1s to cancel the "synchronous recording" function.

③Press Turner's left footswitch and right footswitch at the same time to enter the tuner mode, and press any Turner footswitch to exit the tuner mode.



FAQ

1、**The device does not work.** A:①Must use DC 9v(⊖-◆-⊕)②Make sure the guitar and speakers are properly connected.③Make sure the footswitch is pressed and the screen is displayed correctly.

2、**Noisy playback.** A:Check whether the connection is correct, whether the speaker has a ground wire, and is the cable normal.

3、**Whether loop is connected before or after other effects.** A:①loop in front, only the acoustic guitar sound is recorded；②loop behind， the recording retains the sound effects polished by other effects.

4、**After SYN recording is turned on, the recording function cannot be activated.** A:Try to increase the output volume of the instrument.

Specification

Maximun loop length	1116s
Single loop recording time	372s
Overdubs recording time	Unlimited
Number of loop	3
USB	Micro-USB
Input Jack	1/4" mona jack
Output Jack	1/4" mona jack
Power Supply	DC 9V(⊖-◆-⊕)
Working Current	100mA (DC 9V)
Input Impedance	1 M Ohms
Output Impedance	100 Ohms
Weight	300g
Dimensions(length×widthxheight)	90(D)x40(W)×49.5(H)mm
Accessory	Owner's Manual, USB cable, Wireless Turner(Purchase separately)

LEKATO
www.lekatodeal.com

●拡張ペダルを接続します。LOOP AUTOホストボックスに含まれているUSB2.0ケーブルを使用してLEKATO拡張ペダルを接続できます。この拡張ペダルを使用すると、デバイスの操作をより便利に行うことができます。LOOP AUTOホストがLEKATO拡張ペダルに接続されている場合、拡張ペダルをオン（電源）にしたり、プラグを差し込んだりする必要はありません。

①拡張ペダルの左ペダルを短く押す、前の曲に切り替える、拡張ペダルの右ペダルを短く押す、次の曲に切り替える。

②拡張ペダルを長押しして左右の釘を1秒間踏むと「同期録音」モードに入り、1秒間押し続けると「同期録音」機能が解除されます。

③エクスパンションペダルの左右のペダルを同時に踏むとチューナーモードになり、エクスパンションペダルを踏むとチューナーモードを抜けることができます。



よくある質問

1.デバイスが機能しない
回答：①電源アダプターはDC9V（⊖-◆-⊕ ）である必要があります。②ギター、ペダル、スピーカーが正しく接続されていることを確認してください。③フットスイッチが押され、LED画面が正しく表示されていることを確認してください。

2.再生時にノイズが発生する
回答：配線が適切に接続されているかどうか、スピーカーがアース線に接続されているかどうか、ケーブルが正しく機能しているかどうかを確認してください

3.LOOPは他のエフェクトの前後に接続されます
回答：①LOOPは他のエフェクトの前に接続されており、録音のオーディオエフェクトはギターのオリジナルサウンドのみです。
②LOOPを他のエフェクターに接続した後、録音されたオーディオは他のエフェクターによって磨かれた効果音を保存します。

4.同期記録をオンにした後、記録機能をアクティブにすることはできません
回答：機器の出力音量を上げてみてください。

LOOP AUTOの技術パラメータ

総録音時間	1116秒
合計LOOP記録時間	372秒
オーバーレイ録音時間	無制限
ループの総数	3曲
USBリンクタイプ	Micro-USB
入力接続タイプ	標準の1/4インチインターフェースモノラル/ TS
出力接続タイプ	標準の1/4インチインターフェースモノラル/ TS
電源入力	標準の9V直流（内側が負、外側が正）
動作電流	100mA(DC 9V)
入力抵抗	1M ohm
出力インピーダンス	100ohm
重量	300g
寸法（長さX幅X高さ）	90（D）X40（W）X49.5（H）mm
付属品	マニュアル; USBケーブル;専用ペダル（別途購入が必要）

LEKATO
www.lekatodeal.com

AUTO说明书(英日)					备注
V01	比例	1:1	日期	2021-06-03	先印英文在印日文
关关	印刷	彩印	尺寸	折后:100x55mm	
128克铜版纸	工艺	骑马钉			
陈耀东	批准		公司	珠海笙科智能科技有限公司	