Operation Manual

SPYCRUSHERS
CLOTHES HOOK CAMERA

SPYCRUSHERS

www.spycrushers.com

BEFORE YOU BEGIN

IMPORTANT NOTE: Prohibition against eavesdropping

All jurisdictions have specific laws and regulations relating to the use of cameras and video recorders. Before using any camera or video recorder for any purpose, it is the buyer's responsibility to be aware of all applicable laws and regulations that prohibit or limit the use of such products and to comply with the applicable laws and regulations.

PACKAGE CONTENTS

- 1 SpyCrushers Clothes Hook Camera
- 1 Mini USB Cable
- 1 Mounting Bracket
- 2 Mounting Screws
- 2 Double-Sided Tape Strips

SPYCRUSHERS CLOTHES HOOK CAMERA LAYOUT

1. Video Start/Stop Button 2. Camera 3. Reset 4. Status Indicator
5. Micro SD Card Slot 6. On/Off 7. Mini USB Cable Port

Operating Instruction

***Please fully charge device before use. The first three (3) times charge the device at least 8-12 hours to achieve maximum performance.**

Turn On

- Insert Mini SD Card into its slot. (#5 in layout diagram)
- Switch the ON/OFF button to the ON position. (#6 in layout diagram)
- Press and hold the video start/stop button (#1 in layout diagram). The status indicator light will flash repeatedly and go solid (#4 in layout diagram) and the devcie is now on and in standy mode.

Turning Off

- While in standby mode press and hold the video start/stop button until status indicator light flashes repeatedly and then goes out. The device has shut down saving all media files automatically. Release the button
- The device can also be turned off by switching the ON/OFF switch to OFF. This also resets the device so use this option only if necessary.

Recording Video:

- **Manual Video:** Turn on the device. While in standby mode press the video start/stop button the status indicator light will flash 3 repeatedly and go out. Video is now being recorded (#2 in layout diagram). To stop recording press vidoe start/stop button the status indicator light will go solid and device will enter standby mode and save all recorded video.
- **Motion Detection Recording:** Turn on the device. While in standby mode press the video start/stop button (#1 in layout diagram) twice the status indicator light will flash repeatedly and go out and into motion activated mode. Video will start recording when motion is detected. To stop recording press vidoe start/stop button the status indicator light will go solid and device will enter standby mode and save all recorded video.

  Note: In both cases make sure there is a mini SD Card (up to 16GB) inserted, adequate light and the camera lens (#1 in layout diagram) is not blocked by other items. Recorded objects should be at least 1.5 feet away from the camera. In order to ensure the size and safety of files the Clothes Hook Camera's internal system will save the video files automatically every 5 minutes and continue the video recording. Saving files takes a little time. Do not press the

video start/stop button continuously in order to avoid saving corrupted or incomplete vidoe files.

Downloading and Viewing Video:

- When the Clothes Hook Camera is connected to a computer running Windows XP, Windows Vista, Windows 7 or Mac OS X, the operating system will automatically recognize the device and install the correct drivers. No software is needed.
- Navigate to the new Removable Disk on your computer to view, copy or delete video files just like a portable hard drive or flash drive.
- Playback video recordings on your PC with media players such as VLC, winDVD, powerDVD etc., (not supplied) capable of decoding H263 format AVI files.

Connect to Computer:

- While the Clothes Hook Camera is off it can be connected to your computer using the USB Cable. Plug the USB Cable connector into the Clothes Hook Camera USB port (#7 in layout diagram) and the other end into your computer. The Clothes Hook Camera will be listed as a "Removable Disk". Once connected the Clothes Hook Camera will upload its data to your computer, a status indicator light will blink repeatedly. To disconnect safely please click "Safely Remove Hardware and Eject Media" icon on the right bottom corner of your task bar. Then click the "Eject" choice and unplug the USB cable from both your computer and Clothes Hook Camera.

  Note: If the connection is not recognized within 30 seconds switch device OFF then back ON using the ON/OFF switch (#6 layout diagram) and retry connection.

Charging:

- Connect the Clothes Hook Camera to your computer using the USB Cable. When the battery is charging the status indicator light (#4 in layout diagram) will blink repeatedly or have a static solid light.

  Note: After 2 hours disconnect and use normally. The Clothes Hook Camera can be charged at anytime, but for maximum battery life

please use battery until completely drained and fully recharge to its capacity for the first three (3) times for 8-12 hours each time.

Setting the Date/Time Stamp:

- Connect the Clothes Hook Camera to your computer. Under the Devices and Removable Storage Directory click on and open the "Removable Disk" or the name that represents the Clothes Hook Camera on your computer. Open and find the time or txt file. Open it and rewrite the date and time to the current date and time. **Do not change the format**. Only rewrite to the current date and time. Save file with new date and time. Disconnect USB Cable turn on the device make a new recording and verify.

Reset

- To reset the SpyCrushers Clothes Hook Camera use a toothpick or non-metal pointed object to push the reset button (#3 in layout diagram). Metal objects may damage the SpyCrushers Clothes Hook Camera and should be avoided. This will not reset the time or delete any files. Use this only if the SpyCrushers Clothes Hook Camera is not responding.
- The device can also be reset by switching the ON/OFF switch to OFF. Use this option only if the SpyCrushers Clothes Hook Camera is not responding.

Installation:

- The SpyCrushers Clothes Hook Camera can be placed on any flat surface with the included mounting bracket and screws or with the included double-sided tape.

  Note: Make sure the camera lens (#1 in layout diagram) is not blocked by other items. Recorded objects should be at least 1.5 feet away from the camera.

Cautions

- **Battery:** As the usage time grows, the battery life will shorten. Please recharge battery to its full capacity before using after long periods of inactive use.

- **File Security:** The SpyCrushers Clothes Hook Camera is not a dedicated storage device. SpyCrushers does not warrant the completeness and safety created files. Please back-up the important files onto your computer or other storage device.
- **Video Quality:** The SpyCrushers Clothes Hook Camera is not professional grade video recorder or camera. SpyCrushers makes no assurance that the video or photo quality will meet your particular standards.
- **Operating Temperature:** 0—40°C。
- **Operating Humidity:** 20%—80% , Please do not use this product at above normal humid environment. The SpyCrushers Clothes Hook Camera is not water resistant.
- **Filming:** In order to protect the optics within from the hard light please do not expose lens directly to sunlight or other strong or harsh lighting sources for long periods.
- **Cleaning:** Please only use lens paper or soft eye cloth to clean camera lens .
- **Durability:** The SpyCrushers Clothes Hook Camera is a precision electronic product. Please do not use around high magnetic fields or high electric fields.

Specifications

Subject	Relatively Parameter
Video Format	AVI
Video Encoding	M-JPEG
Video Resolution	1280*960 VGA
Video Frame Rate	25-30fps±1fps
Media Player Software	Most major operating system media players or mainstream media playing software.
Operating Systems	Windows me/2000/xp/2003/vista,7 Mac OS X, Linux
Charging Voltage	DC-5V
Interface-Type	Mini USB
Memory Interface	Not Included
Battery Type	High-Capacity Polymer Lithium Battery

Recording Time Per Full Charge	120 Minutes
Battery Charging Time	8-12 hours for first 3 times. 2 hours thereafer.

Troubleshooting

- **Problem**: The Clothes Hook Camera takes a long time to boot or save recordings.
- **Solution**: Clear or back up some or all of the files from the Clothes Hook Camera. The more storage used up in the Clothes Hook Camera the longer it may take to boot or process saved files.

- **Problem**: Some of my videos will not play on my computer.
- **Solution**: Videos can become corrupt and will not play if the Clothes Hook Camera is not used as described in this manual. Pushing the button several times or holding the button can result in corrupted files. Wait until the Clothes Hook Camera has finished processing before pressing any button again.

- **Problem**: My Clothes Hook Camera will not record.
- **Solution**: Make sure the Clothes Hook Camera is not plugged into a USB port. Make sure the Clothes Hook Camera is charged. Make sure the On/Off switch is set to “ON”.

Warranty Information

SpyCrushers brand and all SpyCrushers products are owned and operated by Crushers, Inc. Crushers, Inc warrants this product against defects in workmanship and material for a period of one (1) year from its original purchase date. You must present your receipt as proof of date of purchase for warranty validation. Any unit which proves defective during the stated period will be repaired without charge for parts or labor or replaced at the sole discretion of Crushers, Inc.. The end user is responsible for all freight charges incurred to send the product to Crushers Inc’s repair centers. The end user is responsible for all shipping costs incurred when shipping from and to any country other than the country of purchase. The warranty does not cover any incidental, accidental or consequential damages arising from

the use of or the inability to use this product. Any costs associated with the fitting or removal of this product by a tradesman or other person or any other costs associated with its use are the responsibility of the end user. This warranty applies to the original purchaser of the product only and is not transferable to any third party. Unauthorized end user or third party modifications to any component or evidence of misuse or abuse of the device will render all warranties void.
By law some countries do not allow limitations on certain exclusions in this warranty. Where applicable by local laws, regulations and legal rights will take precedence.

Crushers Inc.
info@crushersinc.net
© Crushers Corporation Communications 2013

FCC Verification
This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

WARNING: Modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

Connect, friend and follow SpyCrushers for product specials, discounts and more.

http://www.spycrushers.com
http://www.facebook.com/spycrushers
http://www.twitter.com/spycrushers
http://www.youtube.com/user/spycrushers

Click Here For Free & Deeply Discounted Crushers, Inc Products ! Join Our VIPGroup Today!