Pro Series Remote

Power

Reset
All zones reset
to default setting

Color
Select zone then use
dial to pick color

3 Zones

Heat
Cycle between
High-Low-Off

Flame
Select zone then use
wheel or bar

Fade
Cycle between
all colors

Ember Bed
Select zone then use
wheel or bar

Sync
All zones sync
to flame color

Downlight
Select zone then
use wheel or bar

Intensity
Select zone then slide bar to pick any intensity

MODERN FLAMES