TIGERKING

USER MANUAL

PB4(DIGITAL KEYPAD)
PB4-F(BIOMETRIC LOCK)

TIGERKING Pistol Safe

Email:Support@tigerkingsafe.com
Facebook:@TIGERKINGSAFES
Messenger:m.me/TIGERKINGSAFES

Version:V202103

MANUAL

01 STRUCTURE

02 FIRST OPENING
INSTALL BATTERIES

03 CODE SETTING

04 FINGRPRINT SETTING (For PB4-F ONLY)

05 OPEN THE SAFE
KEYPAD TONES ON/OFF
TROUBLESHOOTING

06 CUSTOMER SUPPORT

WARNING

Tigerking safe recommends that you do not store loaded guns in this unit.

If you experience any problems or challenges with your safe, please feel free to contact us for quick response. Many issues can be resolved promptly without the product needing to be returned.

Our customer support team is always available to answer any questions and help to resolve all concerns you may have.

Email:Support@tigerkingsafe.com
Facebook:@TIGERKINGSAFES
Messenger:m.me/TIGERKINGSAFES

STRUCTURE

1 KEYPAD



2 EMERGENCY KEYS

3 FINGERPRINT SENSOR (For PB4-F ONLY)

4 RESET BUTTON

5 INNER BATTERY COMPARTMENT

6 PRE-DRILLED HOLES

Warning: Please do not keep the emergency key inside the safe.

FIRST OPENING

STEP 1: Find the emergency key in the package (one set with two black keys);

STEP 2: Fully insert the emergency key, turn counter clockwise to the limit to open the safe.

Notice: Do not lock key inside safe – this is an override key and will open the safe in the event that you have lost your code.

INSTALL BATTERIES

STEP 1: Remove the battery pack cover(In the left rear of the keypad).

STEP 2: Insert New 4 X AA alkaline batteries.

Notice:

1. Do not use rechargeable batteries or any other type of non-alkaline battery;
2. Do not mix old and new batteries;
3. Do not mix alkaline and standard batteries;
4. The safe doesn't include batteries, you need preprare 4x AA batteries at your side .

CODE SETTING

STEP 1: In the open state, located the reset button in the right rear of the keypad;

STEP 2: Press it shortly and quickly, do not hold down the button. The green indicator will light and beep twice;

STEP 3: Enter a new code with 4-6 digits and press the reset button as confirming;

STEP 4: Re-enter the same new code and press the reset button again as confirming.If enter successfully, the green light will blink and beep twice ; otherwise, the red light will blink and beep twice;

STEP 5: With the lid open, enter the new code again to verify if it has been programmed successfully. The motor of the safe should cycle and the light will turn green if the code is correct.

Notice:

1. All safe models initially work with the factory code 1, 2, 3, 4, It is therefore important to re-program your safe with a new user code;

2. When pressing the reset button, you should press shortly and release then, or if hold down the button over 3s, the programmed fingerprints would be erased; (For PB4-F ONLY)
3. 6s without any operation, the system will go back to standby mode with light turns off, and you need to retry from STEP 1;
4. Only one set of 4-6 digits code is allowed to be programmed by the system.

FINGRPRINT SETTING (For PB4-F ONLY)

The fingerprint database is empty, no fingerprint could be read initially.

STEP 1: In the open state, located the reset button in the right rear of the keypad;

STEP 2: Press it shortly and quickly, do not hold down the button. The green indicator will light and beep twice;

STEP 3: Swipe the first finger across the fingerprint scanner multiple times. The LED will flash green once for each valid scan;

STEP 4: When enough valid scans have been record (usually 3-5 scans), there will be brief pause and the LED light will flash green 2 times to indicate successful programming;

STEP 5: With the lid open, enter the new fingerprint to verify if it has been read successfully. The Motor of the safe should cycle and the light will turn green with bleh and beep once if the fingerprint is correct.

Notice:

1. Up to 5 fingerprints could be registered, if you try to record the sixth, the yellow light will turn on with long beep;
2. When pressing the reset button, you should press shortly and release then, or if hold down the button over 3s, the programmed fingerprints would be erased;
3. 6s without any operation, the system will go back to standby mode with light turns off, and you need to retry from STEP1;
4. Duplicate fingerprint would be reminded with yellow LED lights flash and beep twice.

OPEN THE SAFE

OPEN WITH CODE

If the code is correct, the green indicator will turn on and beep once.

OPEN THE SAFE WITH FINGERPRINT(For PB4-F ONLY)

Put the programmed finger on the sensor directly; if correct, the green indicator will flash and beep once, the safe will open; otherwise, the red light will blink and beep twice.

Notice:

1.The LED light will turn on and last for 30s only after opening the safe with code or fingerprint;

2.Five continuing wrong entries, the alarm will go off with the red light blink and beep 2 minutes. The safe could only be opened by the emergency key during the alarm time. Also, remove the batteries is the only way to stop the alarm.

KEYPAD TONES ON/OFF

Hold down the “2” button on the keypad for over 3s to toggle keypad tones ON/OFF.

TROUBLESHOOTING

DELETE ERROR(For PB4-F ONLY): Only programmed fingerprints can be erased and will be deleted at the same time. The code can not be deleted ,but set a new one to replace.

UNDERVOLTAGE WARNING: To check the battery power, press any button on the keypad. If the battery power is lower than 4.2V, the yellow indicator lights on, the batteries should be replaced immediately to ensure the normal use.

SOUND ERROR: Silence function will influence the sound of keypad, program and alarm, If being turned off, all the sounds will be turned off together; if hold down “2” for over 3s again, the sound will return to normal then.

CUSTOMER SUPPORT & WARRANTY

Where could I find the instruction video? To see the tutorial video:

1. Go to our Facebook : @TIGERKINGSAFES
2. Go to our Youtube channel : https://www.youtube.com/channel/UC7Il4xZAK3s-cGA3JgmI9VA
3. contact us to get the videos (24/7):
Messenger: m.me/TIGERKINGSAFES
Email : Support@tigerkingsafe.com

What should I do if losing the keys?

The information below is important to get replaced keys:
If with Master key -----
The numbers on the master key or the label on the right/left side of the safe
If with emergency key -----
The numbers on the emergency key or the number in the emergency key hole

Customer Support /Warranty

The possible problem you might meet:
1. Cargo damaged
2. Missing accessories
3. Unsatisfied with the safe
4. Or any other setting problem

We encourage you to contact us (24/7):
Messenger: m.me/TIGERKINGSAFES
Email : Support@tigerkingsafe.com

We offer 1 Year Warranty for our client and we shall find solution for you. For details,please refer to our warranty card or contact us at “ support@tigerkingsafe.com”.

Thank you for your time to read

PISTOL SAFE SERIES

TIGERKING

Professional, Efficient, Competitive

PB4-F
(BIOMETRIC LOCK)

PB4
(DIGITAL KEYPAD)

PB3-F
(BIOMETRIC LOCK)

PB3
(DIGITAL KEYPAD)

Please email us to get a special VIP discount code before your next order .