DRUMZZ

TREK - 200

Born to Explore

DF-589

User Manual

The Operating Manual includes the use method and important matters needing attention. Please check and keep it carefully.

Contents

- Safety use rules 01
- Getting to know your Weather Radio 02
- How to charge your Weather Radio 03
- How to charge other devices by radio 04
- How to use FLASHLIGHT READING LAMP or SOS ALARM 05
- How to use Bluetooth speakers 06
- How to use radio (AM/FM/Weather) 08
- Specifications 09
- Warranty 10

Thank you very much for this purchase. Please read carefully the instructions before use. Be sure to read the "Safety Rules" before using the product. After reading it, please keep this manual properly.

Safety use rules

- Do not use the Weather Radio in the rain or in places of extreme heat or humidity. Do not let it get wet. Do not touch it with wet hands. Do not place it near a heat source (stove, oven, etc.) or place it in a place where it will be exposed to direct sunlight.
- Do not disassemble, modify or attempt to repair the product. Caution: Risk of electric shock and injury. Do not insert foreign objects into the product.
- Use of Bluetooth when using cellphone, please find the instructions of your cellphone for more details.
- Do not use or operate alarm or sounding device in a way that may cause injury to people or damage to property. Do not use the Alarm for such as a flashlight.
- Do not use the Weather Radio in hazardous USB charging cable for charging the radio. Otherwise there is a risk of fire, electric shock and injury.
- Do not tie up the charging cable or place objects on it. Do not place it near a heat source.
- Do not expose the device to strong impacts such as dropping or throwing it.
- Do not expose your radio to sunlight. Otherwise, it may cause fire, explosion or injury.
- Do not place it in places facing the sun or under the sun. Otherwise, it may cause fire or injury.
- Do not insert external objects into the ports or connectors. Otherwise, it may cause fire.
- Do not dry the radio. Otherwise it is not safe, or there is a risk of fire or electric shock.
- Do not wipe the electronic body with thinner gasoline or benzene.
- Please put in little volume listening products in the under the circumstances of traffic and outdoor.
- Do not use it there are any discernible such as odor, heat, deformation, discoloration, or other abnormalities.
- Do not let people near the ear of children, disabled, or old people. Do not let children or pets bite the product.
- Power cutting the USB charging cable if it is not used for a long time.
- Please do not use or place the device in a place where it is exposed to water.
- When disposing of it, please follow the rules/ regional regulations of the local authorities.

Please keep this manual for future reference. If you lose the manual, you can download it from the website. Please be aware of the safety instructions.

Getting to know your Weather Radio

- ①Power button (ON / OFF, setting power)
- ②Tuning knob
- ③Tune / Memory button (press and hold)
- ④Tune / Memory button (short press)
- ⑤Antenna
- ⑥Bluetooth indicator
- ⑦Power indicator
- ⑧Charging indicator
- ⑨Speaker
- ⑩Flashlight
- ⑪Reading lamp
- ⑫USB charging port
- ⑬USB charging port
- ⑭Tune / Memory button (short press)
- ⑮Volume +
- ⑯Volume -
- ⑰Tune / Seek up
- ⑱Tune / Seek down
- ⑲Power / Mode
- ⑳Flashlight
- ㉑Reading lamp
- ㉒SOS Alarm
- ㉓Tune / Seek down
- ㉔Tune / Seek up
- ㉕Volume -
- ㉖Volume +
- ㉗Tune / Memory button (short press)
- ㉘Tune / Memory button (press and hold)

- ① Hook
- ② Flashlight
- ③ Reading lamp
- ④ Bluetooth indicator
- ⑤ Tune / Memory button (short press) to select the next channel
- ⑥ Power button
- ⑦ Tune / Memory button (press and hold) to save the current channel
- ⑧ Power indicator
- ⑨ Charging indicator
- ⑩ Tune / Seek up
- ⑪ Tune / Seek down
- ⑫ Volume +
- ⑬ Volume -

Notice

- ① Hook, Handle
- ② Flashlight/Reading lamp
- ③ Bluetooth indicator
- ④ Tune / Memory button (short press) to select the next channel
- ⑤ Power button
- ⑥ Tune / Memory button (press and hold) to save the current channel
- ⑦ Power indicator
- ⑧ Charging indicator
- ⑨ Tune / Seek up
- ⑩ Tune / Seek down
- ⑪ Volume +
- ⑫ Volume -

Power supply

- ① Power button: Turn on / off the radio.
- ② Tune / Seek: Tune to the next / previous station and the menu.
- ③ Volume: Adjust the volume.

Using battery

- ① Open the battery cover.
- ② Insert the battery.
- ③ Close the battery cover.

Charging time: 5 hours

How to charge your Weather Radio

Charging method when using a USB (Type-C) charging cable

Charging time: Charging time is about 5 hours. Please do not charge under the sunlight.

- Please use the USB charging cable that has been provided. Otherwise, there is a risk of fire or electric shock and injury. Do not use the USB charging cable for other products. Do not use the USB charging cable that has been damaged or modified. Do not place heavy objects on the USB charging cable. Do not place the USB charging cable near a heat source (stove, oven, etc.) or place it in a place where it will be exposed to direct sunlight.

Charging time: Charging time is about 5 hours.

Caution

- Do not use other chargers and do not charge the charging cable. Otherwise, there is a risk of fire, electric shock and injury.
- When charging with a USB port, it may not charge properly. Be sure to use the USB charging port. Do not use the USB charging port for other connected devices. Do not use a USB extension cable.

- ① Open the USB charging port cover.
- ② Insert the charging cable into the USB port.
- ③ Close the USB charging port cover.

How to charge other devices by radio

- Please do not use the charging cable for other products. Do not use the charging cable that has been damaged or modified. Do not place heavy objects on the charging cable. Do not place the charging cable near a heat source (stove, oven, etc.) or place it in a place where it will be exposed to direct sunlight.
- Please do not use or place the device in a place where it is exposed to water.
- When charging, if it, please follow the rules/ regional regulations of the local authorities.

- ① Open the USB port cover.
- ② Insert the USB charging cable of the device into the USB port.
- ③ Close the USB port cover.

How to use FLASHLIGHT READING LAMP or SOS ALARM ●●

Flashlight and reading lamp

- Turn on the flashlight and reading lamp, and press again to turn off the light.

Alarm of SOS ●●●

- Press and hold the SOS button at the bottom of the body. The alarm will sounding and the SOS light will flashing.
- Press and hold the SOS button again, and the alarm will stop. Please check the flashlight and reading lamp.

How to use bluetooth speakers

- Please make sure the Bluetooth function of your cellphone is turned on.

Pairing

- ① Turn on the radio and the Bluetooth of your phone.
- ② Search the Bluetooth device, and find the radio is connected.

Pairing by NFC

- ① Turn on the NFC on the phone and the Bluetooth function.
- ② Pairing the radio and the phone.

Switch to the next song

- ① Press and hold the Tune button on the Bluetooth function when playing music, and the radio will switch to the next song.

How to use radio (AM/FM/Weather)

Manual search (AM/FM)

- ① Turn on the radio, and the Tune button on the radio will stay on the last station.
- ② Press and hold the Tune button on the radio, and the radio will start to search the next station. Release the button when the radio is tuned to the station you want to listen to.

Automatic search (AM/FM)

- ① Turn on the radio, and the Tune button on the radio will stay on the last station.
- ② Press and Tune button on the radio, and the radio will start to search the next station. Release the button when the radio is tuned to the station you want to listen to.

Manual search (AM/FM)

- ① Turn on the radio, and the Tune button on the radio will stay on the last station.
- ② Press and Tune button on the radio, and the radio will start to search the next station. Release the button when the radio is tuned to the station you want to listen to.

Manual search (AM/FM)

- ① Turn on the radio, and the Tune button on the radio will stay on the last station.
- ② Press and Tune button on the radio, and the radio will start to search the next station. Release the button when the radio is tuned to the station you want to listen to.

Set memory

- ① Pressing the "TUNE" button for 2 seconds, the radio will automatically save all channels in memory.

Set Weather alarm (Weather)

- When alarming, the Weather alarm will stop the alarmed by the Weather alarm if pull the Hook back slowly.

- When alarming, Weather alarm will stop the alarmed by the Weather alarm if pull the Hook back slowly.

- The DRUMZZ Weather is a dedicated channel for receiving weather broadcast information in the United States and Canada. **It is only available in the United States and Canada.**

Set time

Weather channel search

- Press and hold the Tune button on the Weather channel search, the radio will automatically search the weather channel. Release the button when the radio is tuned to the station you want to listen to. The radio will automatically save the weather channel in memory. Please check the Weather channel in the Weather channel search.

Weather channel search

- Press and Tune button on the Weather channel search, the radio will automatically search the next station. Release the button when the radio is tuned to the station you want to listen to. The radio will automatically save the weather channel in memory. Please check the Weather channel in the Weather channel search.

Weather channel search

- Press and Tune button on the Weather channel search, the radio will automatically search the next station. Release the button when the radio is tuned to the station you want to listen to. The radio will automatically save the weather channel in memory. Please check the Weather channel in the Weather channel search.

Weather channel search

- Press and Tune button on the Weather channel search, the radio will automatically search the next station. Release the button when the radio is tuned to the station you want to listen to. The radio will automatically save the weather channel in memory. Please check the Weather channel in the Weather channel search.

Weather channel search

- Press and Tune button on the Weather channel search, the radio will automatically search the next station. Release the button when the radio is tuned to the station you want to listen to. The radio will automatically save the weather channel in memory. Please check the Weather channel in the Weather channel search.

Specifications

Frequency range	FM: 87.5 MHz ~ 108 MHz; AM: 530 kHz ~ 1710 kHz
Power Supply	Rechargeable 3.7V 2.5 Li-polymer battery 2000 mAh
Charging time	Charging time is about 5 hours.
Amplifier	Max 300 mW
Charging time	Approx. 5 hours (using USB)
Battery life	Approx. 10 hours
Bluetooth version	Bluetooth 5.0
USB output	5V / 500 mA
Dimensions	7.5 inch (Length) x 3.5 inch (Width) x 3.5 inch (Height)
Weight	Approx. 1.6 lbs
Operating Temperature	14°F ~ 122°F
Storage Temperature	-4°F ~ 140°F
Operating Humidity	10% ~ 90%
Storage Humidity	10% ~ 90%
Accessories	USB Charging Cable, Manual
Warranty	1 year

For the improvement of products, specifications and appearance may be changed without prior notice.

Warranty

Products	Warranty Commitment
DF-589	12 Months Good warranty