Theme Series

XVX S-K80

User Manual

Keyboard features

Top view

OLED display

Select the screen by turning the knob.

Boot screen

Support for custom startup screen.
Note:The programmer is only for Windows system currently.

Requirements: gif，under 259 Frame (240 x 135pixels recommended)

Home screen

The OLED display will show the following status of items enabled/disabled.

- Battery Status
- Win Mode
- Mac Mode
- Win Lock
- Caps Lock

Functions setting screen

Wired Mode

Type-C cable length: total length 1800mm±30mm.
The keyboard is connected to the host through a cable signal line, and the arrangement of the PIN pins of the interface is as follows:

Backlight effect / color control

1. Use the combination Key Fn + ← / → change the screen to this page.



2. Use the combination Key Fn + Enter to enter the Backlight effect/Colour selection page.



3. Use the combination Key Fn + ↑ / ↓ select the Backlight effect/Colour.

4. Use the combination Key Fn + Enter to confirm the Backlight effect/Colour.

Backlight brightness/speed control

1. Use the combination Key Fn + ← / → change the screen to this page.

2. Use the combination Key Fn + Enter to enter the Backlight brightness/Speed control selection page.

5. Use the combination Key Fn + ← / → Increase/Decrease the Backlight brightness/Backlight brightness/Speed control, Total 5 levels optional: 0%-25%-50%-75%-100%.

4. Use the combination Key Fn + Enter to confirm the Backlight brightness/Speed control.

Volume / language setting

1. Use the combination Key Fn + ← / → change the screen to this page.

2. Use the combination Key Fn + Enter to enter the Volume/Language selection page.

3. Use the combination Key Fn + ↑ / ↓ select the Volume/Language.

4. Use the combination Key Fn + Enter to confirm the Volume/Language.

Keyboard Bottom Switch Instructions

Multimedia key for windows

Fn + F1	Screen brightness -	Fn + F7	Previous playlist
Fn + F2	Screen brightness +	Fn + F8	Play/Pause
Fn + F3	Task switching(WIN+Tab)	Fn + F9	Next playlist
Fn + F4	My computer	Fn + F10	Mute
Fn + F5	Search	Fn + F11	Volume -
Fn + F6	Screenshot	Fn + F12	Volume +
Fn + WIN	Unlock/lock WIN	Fn + ESC	Hold for 3 seconds to restore factory settings
Fn + Home	Home	Fn + ↑	Scroll
Fn + End	End	Fn + ←	Switch display interface/ function backward
Fn + Enter	Confirm the function selected on the display	Fn + →	Switch display interface/ function forward

Multimedia key for Mac

Fn + F1	Screen brightness -	Fn + F2	Screen brightness +
Fn + F3	Task switching	Fn + F4	Fast access
Fn + F5	Search: Short press (SIRI: Long press	Fn + F6	Screenshot
Fn + F7	Previous playlist	Fn + F8	Play/Pause
Fn + F9	Next playlist	Fn + F10	Mute
Fn + F11	Volume -	Fn + F12	Volume +
Fn + Home	Home	Fn + ↑	Scroll
Fn + End	End	Fn + ←	Switch display interface/ function backward
Fn + Enter	Confirm the function selected on the display	Fn + →	Switch display interface/ function forward
Fn + ESC	Hold for 3 seconds to restore factory settings		

Product basic

https://www.xvxchannel.com

instagram.com/xvx__keyboard facebook.com/xvxkeyboard