EPEIOS

取扱説明書 | 사용 설명서 | User Guide

EPEIOS "HummingBird" Cold Brew Maker
喫茶店流 水出し珈琲抽出器 蜂鳥の形
EPEIOS "Hummingbird" Cold Brew Maker

Model: EPC0801

1 / 4

目次

安全にご使用いただくために……01
製品紹介……02
取り付け図……03
製品の使用方法……04
洗浄・お手入れ……07
トラブルシューティング……07
保証書……08

EPEIOS製品をお買い上げいただき、誠にありがとうございます。
本製品を使用する前に、本マニュアルを必読みいただき、安全な使用・保管をしてください。

목차

안전 주의 사항……09
제품 개요 설명……10
제품 소개……10
설치방법……11
제품 사용 설명……12
세척 및 보관……15
고장 안내……15
보증서……16

EPEIOS 제품을 구입해 주셔 감사합니다.
제품을 사용하기 전엔 반드시 설명서를 읽으신 후 사용하시기 바라며 추후 참고용 위해 잘 보관해 두시기 바랍니다.

Contents

Important Safety Cautions……17
Get to Know the Product……18
Specifications……18
How to Install……19
How to Use……20
Cleaning and Maintenance……23
Troubleshooting……23
Warranty Card……24

安全にご使用いただくために

使用前に取扱説明書をよく読み、大切に保管してください

1. 効果に影響が出たり、故障の原因となりうるとございますので、家庭用電源が適切かどうか確認してください。
2. 高温の場所で使用や保管はしないでください。
3. 使い終わりや本製品を洗浄する際は、電源を切ってください。
4. 本製品は、テーブルの上や平らな場所に置くようにしてください。また、USB充電ケーブルをテーブルやカウンターの端に近づけないでください。
5. 充電する際は、メインユニットは外を付けたままの充電はしないでください。
6. 内部電流が流なので、本製品は低温室な環境で保管してください。
7. 本製品の破損や人身事故、故障の原因となりますので、付属品以外のパーツなどを本製品に使用しないでください。
8. 運転開始前に、本体を含むパーツを全て組みなおしてからタイマーを押してください。
9. カップには炭酸飲料や果汁などを入れないでください。
10. 本製品に不具合がある場合、または その他の原因で正常に動作しない場合において、自分で分解しないでください。危険を避けるため、購入した店舗または カスタマーサポートにお問い合わせください。
11. 電源コードが破損した場合は、メーカーまたはカスタマーサポートにお問い合わせください。
12. 以下に該当する方は取扱いに注意が必要です。
--身体的、感覚的、または精神的な障碍をお持ちの方（子どもを含む）、または その他の障害により、適切な使用ができないと方法。当人の安全に責任を負う人が監督または指示していない場合において本製品を使用しないようにしてください。
--お子様が本製品で遊ばないように、必ず保護者の方が監視してください。
--最長の洗浄とお手入れは、保護者の方がいない子どもものの状況では行わないでください。
--使い終わりや お手入れ中は、本体と電源を切り、子どもが手に取って遊んでしまわないようにしてください。

ご注意

バッテリーを分解・改造した場合の保証に使用しないでください。
バッテリーを火に近づけると爆発する恐れがあります。
バッテリーは、地域の方針に従って安全な方法で廃棄してください。
充電アーバルは本製品に充電しない際にはUSBアダプターなどから抜いて保管してください。また、充電ケーブルに損傷しているアダプターに並属な他のものに接触しないようご注意ください。

07

제품 소개

메인 유니트[본체]: 스테인레스 재질의 액체를 넣는 용기입니다.
스테이너: 커피 분말 등을 거르는 부분입니다.
필터: 커피 분말 가루, 찌꺼기 등을 거르는 부분입니다.
컵: 물 등 액체를 넣는 용기입니다.
휴대용 주전자: 컵 아래에 장착하여 휴대하기 편리한 주전자입니다.
다기능 브러시: 세척 시 좁은 부분 등을 깨끗하게 하기 위한 브러시입니다.

전원버튼 램프의 설명

15분주기 : 전원 켜고 15분 경과 후 15분 간격으로 점등합니다.
30분주기 : 전원 켜고 30분 경과 후 30분 간격으로 점등합니다.

팬 모터의 설명

15분주기 : 전원 켜고 15분 경과 후 15분 간격으로 팬 모터가 작동합니다.
30분주기 : 전원 켜고 30분 경과 후 30분 간격으로 팬 모터가 작동합니다.

사용 방법

1. 전원 버튼을 눌러 전원을 켜면 메인 유닛 작동을 한 번 표시등이 켜집니다.
2. 충전 모드에서는 표시등이 깜빡입니다.
3. 충전이 완료되면 표시등이 꺼집니다.
4. 배터리가 부족할 시 작동 불가하며 전원 버튼을 누르면 충전을 하도록 표시등이 깜빡입니다.

버튼 조작 설명

1단계 충전도: 전원 버튼을 한 번 누르면 1.5분 충전모드가 작동되며 표시등은 5초 간격으로 깜빡입니다.
30분 충전도: 전원 버튼을 두 번 누르면 30분 충전모드가 작동되며 표시등은 주 줄을 날려 까지 켜 켜집니다.

경고:

① 배터리를 분해, 개조하거나 다른 용도에 사용하지 마십시오.
② 배터리가 폭발할 수 있으므로 불 속에 넣지 마십시오.
③ 지역 정책에 따라 배터리를 안전하게 폐기하십시오.

제품 스펙

제품명	에페이오스 허밍버드 콜드브루 커피 메이커
모델명	EPC0801
소비 전력	DC3.7V
정격 전압	어댑터 입력 100-220V 50/60Hz, 출력 DC5V ⎓1A
배터리 용량	900mAh (Max)
제품 용량	680ml (Max)
소재	≤65dB
용기 본체 내열 온도	≤90℃ (해당 온도 이상의 물이나 기타 액체 사용 금지)
추출 농도	≥1.0PPM (5min) ≥ 1.2PPM (30min)
추출 압력	57mmHg (7.6Kpa)
제품 무게	0.5kg

10

설치 방법

메인 유닛(본체) | 내부 용기 | 필터 | 상단 용기 | 보틀 용기

Step 1

메인 유닛(본체)
내부 용기

Step 2

필터

Step 3

상단 용기
보틀 용기

Step 4



11

사용 설명

처음 사용

1. 본 제품을 처음 사용하기 전에 본체를 깨끗한 모든 부품을 자극이 없는 세정제로 깨끗이 세척하고, 본체는 찬은 찬모로 닦아주고 물에 잘가서는 안 됩니다.
2. 더 좋은 제맛을 위해 첫 사용 전에 배터리를 완전히 충전하고 제품과 함께하는 부품을 깨끗이 세척해 주십시오.

충전 모드

1. 전개용의 5V ⎓ 1A 에 해당하는 어댑터에 지정된전압을 연결하고 타기하드를 본체에 연결하여 충전하여 (그림 1 참조).

(그림1)

2. 필터에 커피가루를 30-40g 정가하고, 커피가루의 사용량은 취향에 따라 조절하며, 최대 농도를 위해 상한 일정 제품 용량을 넘지 않도록 하십시오 (용량 배이 있, 용량 그라인딩 커피 파우더 사용 권장) (그림 5 참조)

(그림2)

3. 조립한이 완료되면 표시등이 켜집니다.
비고: 제품이 처진상 상태가 되면(저등 불 가), 전원 버튼을 눌 우은 충전하라는 메시지가 깜박입니다.

(그림3)

12

제품 가동 설명

보틀 용기: 물이나 우유 등의 액체를 넣는 용기입니다. 용량은 520ml~680ml입니다.
메인 유닛[본체]: 내부 용기가 들어가 있는 부분입니다. 전자 장치가 탑재되는 장치입니다.
내부 용기: 원료이나 분말 등 넣을 수 있습니다. 내부 용기의 깊이 깊이 등의 추가하는 것을 권장합니다.
필터: 커피 원두 가루, 찌꺼 등 기타의 제품 넣는 용기입니다. 원두 가루 최대 40g 정말 최대 이상을 넣 수 있습니다.
휴대용 주전자: 보틀 용기의 컵 아래에 휴대하기 편리한 주전자입니다.
다기능 브러시: 세척 과정에 좁은 부분을 깨끗하게 하기 위한 브러시입니다.

세척 보관 방법

1. 세척 전 제품의 작업 종지 모만는 지 확인하세요.
2. 와이어 등, 연마성 세제의 또는 가솔린, 디새벤 등의 부식성 액체를 사용하여 세척하지 마십시오.
3. 본체는 마른 행주로 닦을 수 있으며, 전기기기가 손상되거나 제품이 누전되지 않도록 물이나 다른 액체에 젖구거나, 물에 잠기지 마십시오.
4. 본체 이외의 부분은 세정제를 넣은후 브러쉬로 가볍게 문질러 주어야 닦아줍니다.
5. 수납보관시 제품이 깨끗하게 건조되도록 통풍이 잘되고 직사광선이 닿지 않는 곳에 보관하세요.

비고: 리이어 표절작인 작동을 위하여 제일 지켜야 수칙은 전기기기의 사용빈도에 따라 정기적으로 따라줍을 제거하세요. 구체적으로는 식초 용액(식초 1개, 물 3개)을 검재 적당량 붓고 커피기루를 넣지 않고 중 해주 시 식초 냄새가 나지 않을 때까지 물로 반복 세척하면 됩니다.

고장 안내

고장 안내	원인분석	해결방법
추출한 커피맛이 연하고, 맛이 없습니다.	원두가루가 적거나 배터리가 부족하여 제시간대로 작동이 이루어 지지 않았습니다.	갓구워졌 원두가루를 넣으주신 후 배터리를 완충하고 사용하세요.
본체 내부로 물수 및 분사 됩니다.	프로펠 탈장이 로 휘발 상상하거나 원두 찌꺼기가 위를 덮어서 작동이 안됩니다.	A.당을 조정하거나 만드로 탈장을 깨끗이 닦아주세요.
공기에 거품이 계속 생겨 됩니다.	탈장이 이물질로 연결돼 라졌을 수 없습니다.	용기에 물을이나 기타 재료를 담기 넣지 마시고, 탈장을 세척하주세요.
전원버튼 LED 표시등이 계속 깜빡거립니다.	배터리가 부족합니다.	배터리를 충전 후 사용하세요.
손잡혼잡이 되지 않습니다.	실링이 파손되었는지 확인해주세요.	실링이 파손되었다면 교환하거나 A.S센터에 요청하세요.

15

보증서

보증기간내 보증수리(무상수리)는 구입일로부터 실시한다

1. 다음의 경우에는 보증 기간 안수등을 제시해 주십시오.
다음 두 가지는 각별히 주의하여 바랍니다.
a. 본 보증서는 분실 후 재발급 되지 않으니 잘 보관해 주십시오.
b. 본 보증서는 본 한해 국가 또는 구역에서만 사용할 수 있습니다.

2. 구입일로부터 이하의 기간 동안 정상 사용 중 고장이 발생한 경우 보증합니다.
--기기본체------1년간 무상

3. 다음의 경우에 속하는 지는 보증기간 내에라도 보증으로 취급할 수 없으나 유료로 수리할 수 있습니다.
a. 사용자 사용설명서에 유구되는 사용, 유지, 보관을 방법대로 하지 않아 파손된 경우;
b. 부정확한 조작으로 인한이 비정상적으로 손상(예: 낙하 등) 파우;
c. EPEIOS A/S부서를 통하지 않고 자체적 수리로 인한 파손 경우;
d. 제품 보관 시 당사 등 구매 영수증을 제시할 수 없을 경우;
e. 보증서에 기재된 정보가 상호 일치하지 않을 경우;
f. 불가항력 요소에 전쟁, 지진, 화재, 수해 등과 인해 파손된 경우;

4. 본 보증서만은 소비자 개인이 생활소비를 위해 구매하여 사용하는 경우에만 적용되며, 영업 등 사용에는 적용되지 않습니다.

모델 EPC0801
구입 날짜 _____년_____월_____일
판매점 정보 （주소 · 판매처 · 전화번호）

여기에 판매점 도장 또는 구입 영수증을 첨부 부 보관하십시오.

16

Important Safety Cautions

Please read this guide thoroughly before use and keep it properly for future reference.

1. Please make sure this product works with your household power supply to achieve the best performance and avoid damages.
2. Do not use this product in high temperatures.
3. Please disconnect from power supply before cleaning this brewer or when not in use.
4. Place this product onto a countertop or other even surfaces. Do not hang the USB cable over the edges of a table or countertop.
5. Do not place this product in high temperatures.
6. Do not use this product while it is being charged.
7. Place this product in a dry environment since it comes with a built-in battery.
8. Use spare parts provided by the manufacturer only to avoid damages or injuries.
9. Cup the main unit before you power it on.
10. Please add water as per the rated capacity.
11. If the product malfunctions or cannot perform normally due to other reasons, do not disassemble it by yourself. And ask authorized retailer or distributor center for help to avoid casualty.
12. If the power cord is damaged, replace it with the dedicated cord or cord provided by the manufacturer or repair center.
13. This product is not intended for use by people with physical, sensory, or mental defects or people lack of experience (including children) unless they are instructed or supervised by a responsible person.
--Take care of your children so they won't play with this product.
--Never let children clean or repair this product without supervision.
--When not in use, during assembly, or before cleaning, please disconnect the product from a power source. Never let children use this product unattended.

Warnings:

1. Do not disassemble, alter, or even remove the battery to other appliances.
2. Do not throw the battery into fire to avoid explosions.
3. Please dispose of the battery according to local regulations.

17

Get to Know the Product

Main Body: Hold water, milk or other liquid, the capacity is 520ml-680ml.
Main Unit: Control part, including filter and inner body.
Inner Body: Hold ice cubes and sugar. We recommend you to fill it half full.
Filter: Hold coffee and tea residues. Hold up to 40g coffee products and 20g tea leaves.
Cup Lid: Combine with the main body for a portable cup for use on the go.
Cleaning Brush: a dedicated brush for removing dirt when washing parts except the main unit.

Power Button and 2 Modes:
Mode 1 (15-Min Extraction): Press the Power Button once to activate Mode 1. The indicator will flash once after every 5-second glowing. Press the Power Button again to stop brewing.
Mode 2 (30-Min Extraction): Press the Power Button twice to activate Mode 2. The indicator will keep on. Press the Power Button again to stop brewing.

Indicator and Charging

1. Once powered on, the indicator around the Power Button will be solid on.
2. During charging, the indicator will keep flashing, and turn solid on when the charging is completed.
3. When brewing is done, the indicator will turn off.
4. When the product is in the low battery (can not be activated), the indicator will flash to remind you to charge the product.

Specifications

Product Name	EPEIOS "HummingBird" Cold Brew Maker
Model	EPC0801
Built-in Battery Output	DC3.7V
Power Supply	Input: 100-220V 50/60Hz, Output: DC5V ⎓1A
Battery Capacity	900mAh (Max)
Bottle Capacity	680ml (Max)

18

Noise	≤65dB
Body Heat-Resistance Temperature	≥90℃ (Do not fill water or other liquid higher than this temperature)
Brewing Density	≥1.0PPM (5min) ≥ 1.2PPM (30min)
Brew Pressure	57mmHg (7.6Kpa)
Product Weight	0.5kg

How to Install

* The images are for reference only

Main Unit | Inner Body | Filter | Upper Cup Base | Body

Step 1

Main Unit
Inner Body

Step 2

Filter

Step 3

Upper Cup Base
Body

Step 4

19

How to Use

Initial Use

1. Before the first use, clean all the parts (except the main unit) with mild detergent and rinse them thoroughly with fresh water. Wipe the main unit with a wet cloth, do not soak it in water.
2. To ensure a better experience, please fully charge the unit before the first use, and wash the parts that directly contact with food thoroughly.

Charging Mode

1. Plug the magnetic charging cable into a power adapter with a rated output of 5V ⎓ 1A, and attach the charging contact onto the main unit for charging. It takes around 2 hours to get it fully charged (Pic. 1).

(Pic. 1)

2. In charging mode, the indicator keeps flashing and the product can not be activated now. (Pic. 2).

(Pic 2)

3. When charging completes, the indicator will be solid on (Pic. 3).
Note: When the product enters low-voltage mode (can not be activated), the Power Button will flash to remind you to charge the unit.

(Pic. 3)

20

Brewing Mode (Coffee)

1. Put the whole machine onto an even surface. Take out the main unit, inner body and filter. Add 520-680ml drinking water into the body, do not exceed the max water level line or under the min water level (Pic.4).

(Pic. 4)

2. Take out the filter, add 30-40g of ground coffee powder into the filter. You can adjust the amount according to your preference, do not exceed the max water level line, install the filter back.
(We recommend you to use medium roast and medium ground coffee beans) (Pic.5).

(Pic. 5)

3. Assemble the main unit, inner body and filter and put them into the main body.

(Pic. 6)

4. Press the Power Button once to enter Mode 1 (15-Min Extraction) and start brewing. The indicator will flash once every 5 seconds while brewing and turns off when 15-minute brewing is done. (see pic.7)
If you want to brew longer, press the Power Button twice to enter Mode 2 (30-Min Extraction), and the indicator will be solid on while brewing.

Notes:

1. Wash your brewing done, press and hold the Power Button to drain water inside the filter.
2. Add a minimum of 520ml water so the filter can be soaked, or brewing won't start.

(Pic. 7)

Use It As a Portable Cup

1. When brewing done, remove the main unit, inner body, filter and upper cup base, install the portable cup lid and rotate it clockwise to tighten it (Pic.8).

(Pic. 8)

2. Put the fingers into the round hole of the cup lid, and enjoy on-the-go (Pic.9)

(Pic. 9)

21

Cleaning and Maintenance

1. Make sure the product has stopped working before cleaning.
2. Do not use hard objects, abrasive detergent or corrosive liquids (gas, acetone) to wash this product.
3. Wipe the main unit with a soft towel. Do not soak or rinse it with water to avoid damages or electric shock.
4. Wipe clean the main unit with a damp cloth that has been wrung out. For cleaning parts except the main unit, use the cleaning brush dipped in mild detergent and gently scrub them.
5. When storing the product, make sure it is clean and dry. Place it in a dry and ventilated place, and avoid direct sunshine.

Note: To ensure further performance, we recommend you regularly cleaning the mineral residues inside the body according to local water quality and use frequencies.

Instructions: Pour proper amount of white vinegar solution (vinegar 1 water 3) into the cup and start brewing without adding any coffee powder. Repeat the process if needed. Drain the solution and rinse it with clean water till the vinegar smell is gone.

Troubleshooting

Problem	Possible Cause	Solution
Brewed coffee is tasteless	Insufficient coffee powder or machine stops working due to low battery	Add coffee powder as per the instructions/ fully charge the device
Water being sucked into the main unit and water leakage	Detection needle failure or opened by coffee residues	Send it for repair or wipe the detection needle clean
Constantly blowing and bubbling	Detection needle dislocated	Do not put too many or other liquid or ingredients into the body, clean the detection needle
LED keeps flashing	Low battery	Charge the device
Failed to cycle water for brewing	Check the sealing ring	Change the sealing ring if broken or send it for repair

23

Warranty Card

From the date of purchase, this product comes with free repair within the warranty period.

1. **Please show this warranty card and your purchase receipt to claim your warranty.**
a) We will not issue another warranty card if you lose your original one.
b) This warranty card only applies to the country or region of your purchase.

2. **From the date of purchase and within the warranty period, repair policy for the malfunctions under proper use.**
Main Body------Free in 1 year

3. **The warranty is void if one of the following terms happens. But we can repair it at a charge.**
A. Damages caused by failure of following the instructions, maintenance, and store conditions as stated in this user guide
B. Damages caused by disassembly of an unauthorized repairing man
C. Failed to provide the warranty card and valid purchase invoice
D. Product information in this guide does not conform with that on the product or has been altered
E. Damages caused by force majeure (thunder, earthquake, fire hazards, flood).

4. **This warranty card only applies to customers who purchased this product for personal care use and does not apply for commercial use.**

Model EPC0801
Purchase date _____
Dealer （Address · Store name · Telephone number）

Please keep it with the store stamp or purchase certificate attached here.

24