QUARTZ 3 HANDS CHRONOGRAPH - 24 HOURS INDICATOR

EARNSHAW
-1805-

A) DISPLAY

Pusher "A"

Hour Hand

Minute Hand

Chronograph Minute Hand

24 Hour Indicator

Pusher "B"

Chronograph Second Hand

Date

1   2   3

B) SETTING THE TIME

1. Pull the crown to position 3.

2. Turn the crown until you reach the correct time.

3. Push the crown back to position 1.

C) SETTING THE DATE

1. Pull the crown to position 2.

2. Turn the crown clockwise until the previous date appears.
* Do not set the date between 9:00p.m. and 1:00a.m.. Otherwise, the date may not change properly. If it is neccessary to set the date during that time period, first change the time to any time outside of it, set the date and then reset the correct time.

3. Push the crown back to position 1.

D) USING THE CHRONOGRAPH

This chronograph is able to measure and display time in 1/1 second united up to a maximum of 1 hour.

Measuring time with the chrongraph. Press the buttons in the following order :

E) CHRONOGRAPH RESET (INCL. AFTER REPLACING BATTERY)

This procedure should be performed when the chronograph second hand does not return to the 0 second position after the chronograph has been reset and after the battery has been replaced.

1. Pull the crown to position 3.

2. Press pusher A to set the chronograph second hand to position 0.

3. The chronograph hands can be maneuvered rapidly by continuously pressing pusher A.

4. Push the crown to position 1.
* Do not push the crown to position 1 while the chronograph second hand returns to 12:00 (ZERO) position.
* Hand stops on the way when the crown is returned to position 1 and these positions are recognised as 12:00 (ZERO) position.