C0/M40/Y80/K0

MADE IN CHINA

USER MANUAL

Wine Cooler Instruction Manual

ND-B-S1

Please Read Carefully Before Operation

8 bottle

NEED ONE TO UPGRADE YOUR LIFE

Thank You for Choosing our wine cooler.

Please read the instructions carefully before operation and then confirm receipt.

If you have any questions or problems, please feel free to contact us for assistance.

CONTENTS

KNOW YOUR WINE COOLER 01

IMPORTANT SAFETY INSTRUCTIONS 02

SPECIFICATIONS 03

ELECTRIC DIAGRAM 04

SETTING THE TEMPERATURE CONTROL 05

INSTRUCTION 06

BEFORE FIRST USE 07

CLEANING & MAINTENANCE 08

TROUBLE SHOOTING 09

WARRANTY POLICY 10

DISCLAIMER OF WARRANTY 11

FCC CAUTION 11

1.KNOW YOUR WINE COOLER

Combined Shelves



Packing List

Model No.	ND-B-S1
Product Dimensions	15.7x17.7x34.6
Package Dimensions (W*D*H) (inch)	17.7x19.7x37.4

2.IMPORTANT SAFETY INSTRUCTIONS

Please read all Danger Instructions and warnings in the user manual before using this equipment.

Danger

1 Do not touch the power supply with wet hands.

2 If there is damage to the plug, power cord or product, immediately stop using the product. If the NAT CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

3 For safe reasons, the wine cooler should be unpacked and assembled by two people. Unplug the power cord before cleaning. Once, the unit is equipped with a grounding lead, it must be connected to a properly grounded outlet.

4 Before connecting the power supply, check that the voltage indicated is compatible or corresponds to the local mains voltage.

5 Do not connect the device to an external timer switch or separate remote control system to avoid dangerous situations.

6 **DO NOT USE ANY MECHANICAL DEVICES OR OTHER MEANS TO ACCELERATE THE DEFROSTING PROCESS, OTHER THAN THOSE RECOMMENDED BY THE MANUFACTURER.**

DO NOT DAMAGE THE REFRIGERANT CIRCUIT.

DO NOT USE ELECTRICAL APPLIANCES WITHIN THE FOOD STORAGE COMPARTMENTS OF THE APPLIANCE.

KEEP THE VENTILATION OPENINGS IN THE APPLIANCE OR IN THE BUILT-IN STRUCTURE CLEAR AND UNOBSTRUCTED.

7 Do not use flammable liquids or other electrical components, as they may cause fire or explosion. Do not place any flammable or explosive substances into your unit. Normal plastic parts are not flammable.

WARNING

The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3.SPECIFICATIONS

Model No.	ND-B-S1
Rated Voltage	110-120V~ 60Hz
Power consumption	70W
Storage Capacity	8pcs
Refrigerant Type	R600a/R134a

TEMPERATURE CONTROL

The temperature control allows you to set the wine cooler to a place where the product can be stored at the optimal temperature. If the optimal temperature is above or below recommended ranges, the performance of the unit may be affected, and extreme cold or hot conditions may cause the internal temperature to fluctuate. You will prevent this against stage from leaving reactive. In addition, keep in mind that the temperature may fluctuate depending on whether the natural light is on or off.

CONTROL PANEL

Temperature Display

Increase/Decrease Button

Temperature Area Button

Light Button

Temperature Area Button

Lighting button is dragged 5s

4.ELECTRIC DIAGRAM

SETTING THE TEMPERATURE CONTROL

1. Light temperature control panel if not operated within 60 seconds, the panel will automatically return to the previous temperature setting. Wait 5 seconds before pressing a button to accomplish resuming the initial operation.

2. Lighting Interface: Press and hold ( ) key for 3 seconds until the cooler lights up. You will hear a "Beep" sound. Light up the LED control to the cooling. 3. Press the ( ) button to increase or ( ) button to decrease the temperature. Press and hold ( ) for 3 seconds to switch the temperature display unit between Fahrenheit and Celsius.

Interior Light

1. You can turn the interior light on or off by lightly press on ( ) button.
2. You need to turn it on whenever loading or unloading the cooling lights.

INSTRUCTION

1. Place the wine cooler in the right place.
2. Place the wine cooler on a level surface and place it in a well-ventilated place.
3. Keep the wine cooler away from heat generating appliances.
4. Place the wine cooler in a sheltered surface that is strong enough to support the weight of the wine cooler. 5. To prevent noise, adjust the front feet to make the cooler stable and level.
6. Ensure the machine is in dry and also place with ambient temperature around 25°C.
7. Before connecting the unit to a power source, allow it stand upright for approximately 3 hours. This will reduce the possibility of any oil-related malfunctions in the refrigerant system from occurring during transportation.
8. Plug the power cord into the socket. Ensure the socket is properly grounded and supplied with a dedicated circuit. Do not use an adapter or extend the power cord. Improper connection may cause fire or electric shock.

POWER CONNECTION

1. Ensure the wine cooler is properly grounded from your safety and in order to avoid electric shock. Failure to ground the power cord in the unit is prohibited. 2. Do not plug. 3. Do not plug which fits well in your high-load outlet.
4. Do not use or remove the ground wire from the supplied power cord. The use of an improper ground wire may cause electric shock.
5. The wine cooler is connected to a 220-240V electrical socket with a 10A circuit plug.
6. Do not connect the unit beyond the wire cooler. Also, do not extend or shorten the power cord. Do not bend or damage the cord.

VENTILATION

1. Ensure that the wine cooler is placed sufficiently well-ventilated.
2. Do not block the ventilation openings in the appliance or in the built-in structure.
3. Keep ventilation openings free of any obstructions.

5.BEFORE FIRST USE

1. Remove all packaging materials, and clean the inside of the wine cooler.

2. Place the wine cooler in the right place.

3. Plug the wine cooler into the right socket.

4. Keep the wine cooler on a level surface and place it in a well-ventilated place.

5. Allow the wine cooler to cool down for at least 2 hours before loading it with wine.

6. Wait for the machine to cool down and place it with ambient temperature around 25°C.

7. Before connecting the unit to a power source, allow it stand upright for approximately 3 hours. This will reduce the possibility of any oil-related malfunctions in the refrigerant system from occurring during transportation.

8. Plug the power cord into the socket. Ensure the socket is properly grounded and supplied with a dedicated circuit. Do not use an adapter or extend the power cord. Improper connection may cause fire or electric shock.

9. Wait for 24 hours before loading the wine cooler. Allow the temperature to stabilize before loading wine.

10. Load the wine cooler with wine.

Note:

Wine cooler cable is fitted with a plug and is not suitable for placement in garages, basements or outdoor areas. It is recommended that it be installed in an ambient temperature between 10° and 38°C. Do not plug in or use an ambient temperature outside this range.

Plug wine cooler permanent and not cut or trim the mains lead. Improper connection may cause fire and electric shock.

Temperature fluctuations, inside the unit, affecting wine preservation. In addition, the temperature can vary, affected by whether the wine cooler is in use.

6. Factory order removal

Clean the inside of your wine cooler by using a mild detergent and warm water.

Let the condensation, if it is visible, dry for "warm" 1 or 2 hours.

Fridge or use newspaper in the fridge overnight. After completing the advice, let the unit run all day to complete the working process.

6.CLEANING & MAINTENANCE

Cleaning steps:

1. Unplug the wine cooler from the power supply and remove the contents and accessories.

2. Clean the inside of the unit with a solution consisting of warm water and baking soda solution (2 tablespoons of baking soda to 1 liquid of water).

3. Turn the interior of the unit, use the detergent and warm water.

4. Wipe the interior with a cloth dipped in a mixture of 2 liquids.

Note: Do not use any harsh cleaners.

Removal and cleaning glass door panel

1. Remove the cleaning glass door panel.

2. Adjust the fastening fitted the hole to avoid damage.

3. Make sure the cooler is in an upright position while cleaning.

7.WINE STORAGE GUIDANCE

1. The ideal temperature for storing wine is between 5a~14°C(1~10°C)

2. Wine should be kept in a place where it will not be subjected to frequent vibrations and avoid freezing if frequently or placing it in a place where it will be subjected to extreme temperature fluctuations.

3. Wine should be stored in a place where it will not be subjected to the sun or other wines. Vibration is also a big disadvantage to wine and accelerates maturation and roughens the wine.

4. After opening the bottle, it is recommended that the wine be kept in a wine cooler with the original cork and stored on vertical racks if possible. It is advisable to consume the wine within a short period of time after opening the bottle to avoid losing the original flavor.

5. Store wines in a proper way and wines are generally best consumed within 3 years.

8.TROUBLE SHOOTING

Problem	Possible Causes	Solution
The cooler not cool enough	The cooler is in a place with poor ventilation	Ensure sufficient space around the cooler
	The door of cooler is not closed tightly	Make sure the door is tightly closed
	Environmental temperature is too high	Make sure the room is not too warm
The cooler is too cold enough	The cooler has been just switched on	The cooler should be adjusted to a cold ambient room or the temperature should be set to a higher level
	The door has been opened too frequently	Minimize the door opening frequency

The cooler is too cold enough	The door is not closed properly	Make sure the door is properly closed
	The door seal is damaged or dirty	Check the door seal and fix it if damaged
	There is a strong heat source nearby	Make sure there is at least 2 inches of space around the cooler
The cooler vibrates or makes noise	The cooler is not level	Adjust and fix the feet of the cooler to level it
	Items are touching the cooling fan	Ensure nothing is touching the fan
The light does not work	Bulb is loose or burnt out	Check the bulb and replace if needed
	The power is not connected or the switch is off	Check the power connection and switch on the cooler
	Interior lighting control is faulty	Contact the manufacturer for assistance

Please scan the QR code on the left of the wine box guide video to watch operating the problem of the above table to solve your problem. If the problem still cannot be solved, please contact us.

As a wine cooler manufacturer, we are committed to providing quality products. However, after closing digital, electronic, and electromechanical products, there may be some unexpected malfunctions. Therefore, please check whether the packaging is intact and whether the product parts are damaged or missing at the first time after you receive it. If there are any problems, please contact us in time. We will provide you with a satisfactory solution, and will assist you in replacing or repairs the damaged or broken.

9.WARRANTY POLICY

- The wine cooler is covered by the manufacturer's limited warranty. This covered of defects in materials and workmanship. This warranty does not cover damage caused by improper handling, improper or inadequate installation, improper maintenance, abuse and misuse, or failure to follow the instructions provided in the manual.
- Use the 220 volt plug or adapter, if any, provided with the product is required for effective and safe operation of the product. Failure to adequately ground the product may cause electrical shock and injury. Do not remove the ground prong from the plug. Do not use an adapter that does not provide a ground connection.
- Do not modify the product in any way and do not attempt to repair the product. Contact the manufacturer or its service agent for repairs. Improper repairs may cause electrical shock and injury.
- Do not use the product for any purpose other than storing food and beverages. Improper use may cause injury or damage to the product.
- Do not use the product in a place where it will be subjected to extreme temperatures, direct sunlight, or other heat sources. Place the product on a level surface and allow at least 2 inches of space around the cooler. Failure to adequately ventilate the product may cause fire and damage to the product.
- Do not place the product in a place where it will be subjected to frequent vibrations. Vibration is a big disadvantage to wine and accelerates maturation and roughens the wine.
- Do not place the product in a place where it will be subjected to the sun or other wines. Keep the product away from heat generating appliances.
- Do not place the product in a place where it will not