GAMESIR

G7 PRO TRI-MODE

Xbox Wired, Mobile & PC Wireless Controller

Model No.: GameSir-G7 Pro
Scan the code for more tutorials ➡
https://gamesir.com/pages/support

PACKAGE CONTENTS

Controller *1 · Charging Station *1 · Receiver *1 · D-pad *2 · Cable Retainer *1
3m Type-C cable*1 · Xbox Game Pass Ultimate Card (1 month) *1
GameSir Sticker*1 · Thank You & After-sale Service Card *1 · Manual *1

REQUIREMENT

*Xbox Series X|S / Xbox One / Android 8.0 or above / PC (Win 10 or above) with USB port

DEVICE LAYOUT

BASIC FUNCTION INTRODUCTION

ACCESSORY REPLACEMENT GUIDE

CONNECTION STATE

Xbox Indicator	Description
Breathing	Reconnecting State *It can connect to previously paired devices.
Running Light Effect (Sequentially Lighting Up)	Pairing State (Bluetooth Mode) *In this state, it can be discovered and paired with devices.
Solid	Connection Successful
Off	Power-off State *The controller will enter power-off state after 10 minutes of inactivity in 2.4G or Bluetooth mode.

OPERATING INSTRUCTIONS

Description	Operation
Power On/Off	Short press the Xbox button to power on. While powered on, press and hold the Xbox button for 5 seconds to power off.
Pairing	In Bluetooth mode, press and hold the pairing button for 2 seconds to enter forced pairing mode.
Preset Configuration Switching	M+Y Default Configuration · M+B Configuration 1 M+A Configuration 2 · M+X Configuration 3
Hair Trigger Mode	Enable/disable hair trigger mode Press and hold the M button + LT/RT button for 2 seconds.
Low Battery	When the battery is below 15%, the Xbox indicator will flash red.
Charging	You can charge the controller via the Type-C port or the charging station.

WINDOWS CONNECTION TUTORIAL

WIRED CONNECTION

1. Use the included Type-C cable to connect the controller to your computer, then press the Xbox button briefly to power on.
2. Once connected successfully, the Xbox indicator will remain solid.

RECEIVER CONNECTION

1. Insert the receiver into the computer.
2. Toggle the controller's mode switch to the 2.4G mode, and press the Xbox button briefly to power on. Wait for the controller to connect.
3. Once connected successfully, the Xbox indicator will remain solid.

ANDROID CONNECTION TUTORIAL

BLUETOOTH CONNECTION

1. Toggle the controller's mode switch to the Bluetooth mode, and press the Xbox button briefly to power on.
2. Open the Bluetooth list on your phone, find the device named GameSir-G7 Pro, and click to connect.
3. Once connected successfully, the Xbox indicator will remain solid.
*If the connection is unsuccessful, press and hold the pairing button on the controller to re-enter pairing status.

XBOX CONNECTION TUTORIAL

WIRED CONNECTION

1. Use the included Type-C cable to connect the controller to the Xbox console, then press the Xbox button briefly to power on.
2. Once connected successfully, the Xbox indicator will remain solid.
* Only supports wired connection.

VOLUME ADJUSTMENT

1. Hold the M button + the D-pad up/down to increase/decrease the main volume (11 levels in total).
* **A sound cue will be provided when adjusting to the maximum or minimum level.**

2. Hold the M button + the D-pad left/right to increase game volume (while decreasing voice volume) / decrease game volume (while increasing voice volume).
* **A sound cue will be provided when adjusting to the maximum, medium or minimum level.**

3. Mute Function: Press the mute button to enable the mute function; the mute indicator will turn solid red. Press the mute button again to disable the mute function (default state); the mute indicator will turn off. While the mute function is active, holding the mute button will temporarily disable it. Release the button to restore the mute function.

EXTRA BUTTON SETTING

Set the extra button value: Press and hold the M button + L4/R4/L5/R5 button, and the Xbox indicator will start flashing slowly. Press the button you want to map to the extra button, and the Xbox indicator will return to a solid light, indicating that the extra button setting is complete.
* Within the setting mode, pressing the corresponding extra button will clear its button value.

STICKS & TRIGGERS CALIBRATION

1. Set the trigger to analog mode, then press and hold + until the Xbox indicator starts flashing slowly.
2. Ensure that the LT & RT triggers and the left & right sticks are not being touched. Then Press the A button. The Xbox indicator will turn off.
3. Press the LT & RT triggers to their maximum travel for 3 times. Rotate the left & right sticks to their maximum angles for 3 times. Press the A button. A solid light on the Xbox indicator indicates that the calibration is complete.

CONTROLLER RESET

If the controller encounters issues such as being unable to power on or off properly, you can use a small object similar to the size of a paperclip to press the Reset button inside the circular hole on the back of the controller. This will force the controller to power off.

CUSTOMIZATION VIA "GAMESIR NEXUS" SOFTWARE

Download the "GameSir Nexus" software from the Microsoft Store on Xbox/PC or from gamesir.com.

⚠ PLEASE READ THIS PRECAUTIONS CAREFULLY

* CONTAINS SMALL PARTS: Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.
* DO NOT use the product near fire.
* DO NOT expose to direct sunlight or high temperatures.
* DO NOT leave the product in a humid or dusty environment.
* DO NOT impact the product or cause it to fall due to strong impact.
* DO NOT overcharge beyond the specified time to avoid malfunctions.
* DO NOT strongly bend or pull cable parts.
* Use a soft, dry cloth while cleaning.
* DO NOT use chemicals such as gasoline or thinner.
* DO NOT disassemble, repair or modify.
* DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
* DO NOT look directly at the optical light. It might damage your eyes.
* If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

WASTE ELECTRICAL & ELECTRICAL EQUIPMENT INFORMATION

CORRECT DISPOSAL OF THIS PRODUCT (WASTE ELECTRICAL & ELECTRICAL EQUIPMENT)
Applicable in the European Union and other European countries with separate collection systems.

This mark on the product or accompanying documents means that it should not be mixed with general household waste for disposal. To prevent potential harm to the environment or human health from uncontrolled waste disposal, please separate this product from other types of waste and recycle it responsibly to promote the sustainable reuse of material resources. For disposal by private users, please contact the retailer from which you purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier for further information. If you do so, you should not dispose of this product together with other commercial waste for disposal. Disposal of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Household users should contact either the retailer where they