

# Jetting Info For K9ES



ITALIAN MOTORS

**K9 ES AB Emulsion Tubes are leaner than AR**

Sat April 28 Chilliwack

Gear 16/23

Fuel Mixture 6% (16:1)

Trans Fluid – Dexron ATF 350ml to fill

End of the Day Weather

**Still Time**

60 F Temp

35% Humidity

44 ALT

99.9 Dens

**Jetting**

Pilot 65-58

Needle K22 #2

Main 168 -160

Air screw 1 turn

Emulsion Tube AB268

**Tape**

3 Stripes


Temp'F 118 - 135

Change main Jet Every 700ALT

If engine runs rich try clip position #1

Pilot

G0 Lean



G8 Rich

Main


150 Lean



170 Rich

Clip

1 Lean



4 Rich

Needle

K21 Lean



K23 Rich