

Rally Management Services
www.rallymanagementservices.com
+1 415-272-4583



Universal Navigation Clamps

Tips:

1. Cut round cross-bar to desired length.
2. Use blue loctite thread locking compound on all screws.
3. Place Teflon tape between handlebars and big part of clamp to allow it to move and minimize damage to the navigation equipment or rider in big impacts.
4. To ensure no slippage: Once you have these mounted in the position you like, drill a 2-3mm deep hole where the clamp set-screws meet the cross-bar.