



**PART #:** BSS-92588-752, BSS-92588-753, and BSS-92588-754 **PRODUCT TYPE:** Corkboard with Wood Frame (24" x 36" and 36" x 48")

**MATERIALS NEEDED:** 2 drywall anchors, 2 screws, and 2 metal mounting brackets (included); level, hammer, pencil, Phillips head screwdriver.



# STEP 1

Determine placement of corkboard on the wall, noting that it will ultimately hang from the metal hanging brackets along the top back edge of the frame.



### STEP 2

Using a level, make 2 pencil marks on the wall where your hangers will go, approximately 12-18" apart.



#### STEP 3

Pre-drill holes for the plastic wall anchors at pencil marks using a 3/16" drill bit.







### STEP 4

Install the plastic wall anchors by hammering them into the pre-drilled holes until they are flush with the wall.





# STEP 5

Install the metal hangers by screwing them into the plastic anchors, with the bent edge of the hanger aligned to the top.



# STEP 6

Hang the corkboard on the metal hangers by sliding the bent edge of the metal hangers inside the top back edge of the wooden frame.