boxta



The Boxta range represents the synergy of ergonomic seat technology and classic clean lines. The moulded Polypropylene back Boxta has achieved certification with the Good Environmental Choice Label which recognises products that meet standards of environmental, quality and social performance. Boxta offers a 3 lever seat and back tilt and a synchronised mechanism. You cannot go past the exceptional benefits of Boxta.

range features:

- Tri-Tek Pressure Reduction Technology
- Dual Density Posture Support seat technology
- X-cel Comfort seat technology
- Standard deluxe seat
- Fabric back design
- 3 lever seat and back tilt
- New improved ratchet back height adjustment
- Moulded Polypropylene back outer
- Geca & AFRDI level 6 Certified

range options:

- Seat slide
- Height adjustable T-arms
- Small or large seat
- Aluminium base
- Heavy duty kit



GREGORY Commercial Furniture

For more information

phone: 13 ERGO (13 3746) email: sales@gcfau.com.au web: www.gcfau.com.au

boxta

product specifications

| Back Height | Product Description | AFRDI | GECA | Seat width | Seat depth (from lumbar) | Depth of seat surface | Seat height range | Back width | Back height range |
|-------------|---------------------|-------|------|---------------|-----------------------------|-----------------------|----------------------|---------------|----------------------|
| Medium Back | Boxta Small DD | 6 | ~ | 460 | 415 | 460 | 530-400 | 400 | 450-520 |
| Medium Back | Boxta Small DD W/A | 6 | ~ | 460 | 415 | 460 | 530-400 | 400 | 450-520 |
| Medium Back | Boxta Medium DD | 6 | ~ | 480 | 435 | 500 | 530-400 | 400 | 450-520 |
| Medium Back | Boxta Medium DD W/A | 6 | ~ | 480 | 435 | 500 | 530-400 | 400 | 450-520 |
| High Back | Boxta Medium DD | 6 | ~ | 480 | 435 | 500 | 530-400 | 400 | 560-630 |
| High Back | Boxta Medium DD W/A | 6 | ✓ | 480 | 435 | 500 | 530-400 | 400 | 560-630 |
| Medium Back | Boxta Large DD | 6 | ✓ | 515 | 485 | 520 | 530-400 | 400 | 450-520 |
| Medium Back | Boxta Large DD W/A | 6 | ~ | 515 | 485 | 520 | 530-400 | 400 | 450-520 |
| High Back | Boxta Large DD | 6 | ✓ | 515 | 485 | 520 | 530-400 | 400 | 560-630 |
| High Back | Boxta Large DD W/A | 6 | ✓ | 515 | 485 | 520 | 530-400 | 400 | 560-630 |

All measurements shown in mm. DD = Dual Density, W/A = With Arms.

Seat depth: The seat depth of the seat is the horizontal distance from the front edge of the seat to the vertical projection of the back supporting point (lumbar). Depth of seat surface: The depth of seat surface is the maximum horizontal distance between vertical lines through the front and rear edges of the seat surface.



