

# MK PREMIUM STONE SEALER

**DIRECTIONS:** Read entire label before using. Follow steps as directed. Make sure surface is clean, and free of waxes and coatings. Test a small inconspicuous area to determine ease of application and desired results. Allow new grout installations to cure for a minimum of 72 hours before proceeding.

**STEP 1:** Protect any adjacent surfaces not intended to be treated.

**STEP 2:** Thoroughly clean surfaces with **MK Neutral Floor Cleaner**, **MK Multi-Surface Cleaner** (for countertops, walls, ledges, etc.) or **MK Intensive Cleaner** and allow to dry completely.

**STEP 3:** Liberally apply **MK Premium Stone Sealer** with an **MK Sealer Applicator**, paint brush, paint pad or roller until the surface is completely covered.

**IMPORTANT:** Do not allow sealer to puddle.

**STEP 4:** Allow **MK Premium Stone Sealer** to absorb for approximately 5 minutes, then buff dry with a clean towel.

**STEP 5:** A second treatment may be necessary for more porous surfaces. Allow the first coat to dry 30-45 minutes and then repeat steps 3 and 4. Regular foot traffic or use may resume within 3-5 hours. For best results, keep the treated surface free from any liquids or soiling for 48 hours. Sealer cures completely within 72 hours.



## MK Premium Stone Sealer

*is another custom blended product made in the USA for*

**Marble Kare Products, Inc.**

