## **REQUIRED TOOLS:**

- 5mm Hex Wrench
- 4mm Hex Wrench
- 3mm Hex Wrench
- 8mm Box Wrench
  [SEE FIGURE 1.]



## **INCLUDED HARDWARE:**

- Mounting Bracket
- M3 X 12mm bolts (2)
- M4 X 15mm bolts (2)
- M4 Locknuts (2)
- *M4 Washers (6)* [SEE FIGURE **2.**]
- Attach Mounting Bracket to lunch rack with M3 X 12mm bolts, washers and M4 Locknuts. Do not tighten down.
  [SEE FIGURE 3.]
- Remove front brake using a 5mm Hex Wrench.
   (Skip step if there is no front brake.)
   [SEE FIGURE 4.]







- Slide brake bolt through Mounting Bracket. \*If no front brake, slide a large bolt through Mounting Bracket that will thread into a Locknut. (Not Included) [SEE FIGURE 5.]
- Tighten down brake bolt into front fork.
   \*If no brake bolt, tighten Locknut onto large bolt into front fork.
   [SEE FIGURE 6.]
- Mount the lower braces to the fork braze-ons with M4 X 15mm bolts and M4 washers using the 4mm Hex Wrench.

  [SEE FIGURE 7.]
- Level the Lunch Rack.
  [SEE FIGURE 8.]
- Tighten all bolts.
  Lunch Rack is installed.
  [SEE FIGURE 9.]









