



## KUNG FU GRIP OF LEGENDS

### INSTALLATION GUIDE

You found your hand slipping on your deck and you dont like to use wax . So you purchased the Slyde Kung fu grip, great choice! and epic grip is coming your way. but first you have to put it on the deck never fear we have your back

It's easy, just pay attention and don't skip any steps. 1 fun hour with a beer!

#### Board Preparation

##### Remove wax

1. **REMOVE THE HAND STRAP** Clean off all the wax with a plastic scraper. Rub off all remaining wax with a Rag. Look at the reflection for any wax you missed.

##### Clean Deck

2. Clean the deck with a rag and de-natured alcohol or lacquer thinner stronger be careful. \$6 Home Depot paint department next to the thinners.

#### Installation

1. Trace your pad with a pencil on your board.
2. Starting at the top point of the Pad, **ONLY PEEL ABOUT 3INCHES OF THE PAPER BACK. DONT TOUCH THE STICKY ADHESIVE.**
3. Just like laying contact paper down on a cupboard shelf; Hold the pad, Perfectly Centered over the board and trace line, Place the sticky top edge inside your traced pencil mark Lightly rest the Adhesive (so you can pull back and reset it ) press from the center out to the edges of the pad.
4. If it looks good, reach under the pad and grab the paper flap, and pull all the paper off the pad

#### Finishing

1. Get a big Plastic Mixing Bowl. Put your hand in the bowl and with smooth pressing strokes, go over: Edges, and Main Pad from top to tail in long smooth strokes. Pop any air bubbles with a tac/needle/pin. Erase the pencil mark with a damp cloth or white eraser..
2. Screw the strap in over the installed grip the grip is specifically designed for the Slyde wedge pro woody and grom series

**SURF, SURF, SURF TILL YOU DIE!**

Slyde Handboards  
Venice

**CALIFORNIA**

90291