

## **No Stank** – Filter Recharge Kit Instructions

Step 1) Remove the end cap and pour out the entire contents for the carbon pellets into a container that will hold more than 5 cups of carbon.

Step 2) Empty contents of **Stage 1** Pellet Carbon into filter tube.

Step 3) Add **Stage 2** granular carbon to complete filling tube to ½” from top of tube on 5/8” models. 1” from top of tube on the 1” model. Lightly tap filter to settle carbon, which will allow you to add slightly more carbon to the filter tube.

Step 4) Install the supplied carbon block filter into the top of filter tube making sure the white end is UP, push edges down around the diameter of filter tube

Step 4) **For 1” filter units only:** After installing the carbon block filter with white side up. Reinstall the green mesh screen at the top of tube. This insures no carbon will spill from filter when installing end caps that are mounted on your vent lines.

Step 5) Replace end cap(s) onto filter housing and return filter to service on your boat.

[WWW.SeaRusSales.com](http://WWW.SeaRusSales.com)