



# WK2 Lower Front Fascia

REMOVAL & INSTALLATION

Removal

**1**

REMOVAL

## Remove quarter-turn fasteners at each corner.

Looking from underneath the lower fascia, locate the (2) quarter-turn fasteners at each corner, (driver & passenger). Turn each fastener 1/4 turn and remove.





**2**

REMOVAL

## Remove quarter-turn fasteners at centre.

Looking from underneath the lower fascia, locate the (3) quarter-turn fasteners at the centre. Turn each fastener 1/4 turn and remove.



**3**

REMOVAL

## **Disconnect corners of Lower Fascia.**

While holding the bumper cover in position with one hand, pull the corner of lower fascia forward with your other hand. The first time may be a bit difficult, but if you are bracing the bumper cover, feel free to give it a good tug until it pops out. Do this on both sides (driver & passenger).





# 4 REMOVAL

## Disconnect Lower Fascia.

With the corners removed, move towards the centre and continue pulling the lower fascia away from the vehicle. It works best if you brace the bumper above where you're pulling. Keep moving along until the lower fascia is completely removed. Be careful not to let the lower fascia fall onto the ground, it is easily scratched.



5

REMOVAL

**Lower Fascia is now fully removed.**



Installation



**1**

## INSTALLATION

### **Attach corners of Lower Fascia.**

Slide the tabs on the corner of the lower fascia into the slots on the bumper cover. Do this on both sides (driver & passenger). It's helpful to have someone hold 1 corner in place while you do the other.



**2**

INSTALLATION

## **Install centre of Lower Fascia.**

Making sure the tabs are aligned with the corresponding slots on the bumper cover, push until the tabs click into place.





**3**

## INSTALLATION

**Install quarter-turn fasteners at centre.**

Looking from underneath the lower fascia, insert the (3) quarter-turn fasteners through the plastic tabs on the air baffle and into the slots in the sub-frame. Turn each fastener 1/4 turn to secure.





## 4 INSTALLATION

### **Install quarter-turn fasteners at each corner.**

Looking from underneath the lower fascia, insert both quarter-turn fasteners and secure. Insert (1) quarter-turn fastener through the slot in the felt wheel well liner and into the slot on the lower front fascia (red). Turn 1/4 turn to secure. Insert (1) quarter-turn fastener through the slot on the lower front fascia and into the bumper cover (blue). Turn 1/4 turn to secure. Do this at both corners, (driver & passenger).





5

INSTALLATION

**Lower Fascia is now fully installed.**







Creating products that enable you and your machine to venture out and experience the beauty and freedom of nature.





+61 7 5522 7340  
Monday - Friday // 8am - 4pm

**WEBSITE**

[www.chiefproducts.com.au](http://www.chiefproducts.com.au)  
[usa.chiefproducts.com.au](http://usa.chiefproducts.com.au)

**EMAIL**

[info@chiefproducts.com.au](mailto:info@chiefproducts.com.au)  
[shop@chiefproducts.com.au](mailto:shop@chiefproducts.com.au)  
[support@chiefproducts.com.au](mailto:support@chiefproducts.com.au)  
[wholesale@chiefproducts.com.au](mailto:wholesale@chiefproducts.com.au)

**ADDRESS**

P.O. BOX 278, MUDGEERABA, QLD 4213  
AUSTRALIA

