

MJBG2000B (Black)
MJBG2000S (Stainless)



Brush Guard for EZ-Go TXT Installation Instructions



Brush Guard



4 Washers

1
Remove bolts from windshield struts.
Retain bolts; you will need them to
attach brush guard to vehicle.



2
Using retained factory hardware
and supplied washers, attach brush
guard to windshield struts.
Tighten bolts.

