



BRUSH GUARD

WILL FIT E-Z-GO® TXT™

INSTALLATION INSTRUCTIONS

MJBG2020B (BLACK)

MJBG2020S (STAINLESS)



INCLUDED:

MADJAX BRUSH GUARD

1
Remove bolts from front struts.
Retain all factory hardware.
You will need it later to attach
the brushguard to the cart.



2
Using retained factory hardware,
attach brush guard to front struts.
Tighten bolts.