



MJCM8000



Convex Mirror Installation Instructions

What's in the box:

1x Convex Mirror

1x Mounting Bracket

2x Self Tapping Screw

1
Mark drill points on horizontal roof strut with a marker or pencil.



2
Drill holes into horizontal strut using a 3/16" bit.



3
Attach mirror bracket to roof strut using included self tapping screws. **Tighten completely.**



4
Screw mirror onto bracket. **Tighten completely.**

