OUTRAGEOUS®

TECH DATA SHEET

Basecoat Blender (NR-6128)

Form: OCF15 Page 1 of 2 Rev. 5/16/06

DESCRIPTION:

Outrageous® NR-6128 Basecoat Blender is designed to make fading and blending custom colours easy. Add NR-6128 Basecoat Blender to basecoat colours for undetectable blends and outstanding appearance. Basecoat Blender NR-6128 can also be used as a protective clear for artwork tape outs on groundcoats. Basecoat Blender prevents the tape from marking or pulling the metallic or pearl basecoats.



RTS

SUBSTRATES:

Repaired original finishes.

MIXING:

No mixing. Ready to use.

POT LIFE:

n/a

APPLICATION:

BLENDING AND FADES:

- 1. Prepare panels as usual. Sand adjacent non-primed areas and panels with P1200 and an ultra fine scuff pad.
- 2. Clean entire area with AR-6120 Outrageous Pre-Wipe or AR-6121 Outrageous Compliant Pre-Wipe and air dry thoroughly.
- 3. Apply one coat of Outrageous NR-6128 Basecoat Blender to the entire area.
- 4. Apply basecoat, according to directions, to the repaired area until full opacity has been achieved.
- 5. Mix by volume, 1 part Outrageous NR-6128 Basecoat Blender with 1 part Outrageous Basecoat Colour. Fade out the surrounding area with reduced air pressure (1.5 bar) and allow to dry.
- 6. For custom fading, always make test panels to achieve desired effect. Start at 2:1 or 3:1 ratio of Basecoat to NR-6128 Basecoat Blender and extend colour. Increase the amount of NR-6128 on each coat, extending the new coat beyond the last coat as desired.

100% Colour		75% Colour		50% Colour		25% Colour		
FADE AREA								
	1		↑	↑	Ť		Ť	
1:0	4:1	3:1	2:1	1:1	1:2	1:3	1:4	

7. Finish by coating the entire area with Outrageous Clearcoat as directed.

Basecoat Blender (NR-6128)

Form: OCF15 Page 2 of 2 Rev. 5/16/06

PROTECTIVE CLEAR:

- 1. Apply 1 or 2 coats of Outrageous NR-6128 Basecoat Blender after the last coat of basecoat colour has flashed.
- 2. Allow 1 hour before taping (tape time will vary with weather and shop conditions).
 - a. Note: Outrageous NR-6128 Basecoat Blender will dry to a semi-gloss feel that is dry to the touch.
 - b. Note: If Outrageous NR-6128 Basecoat Blender dries for more than 1 hour, lightly wet sand with 500 pr 600 grit abrasive to ensure proper topcoat adhesion.
- 3. Do artwork with a minimum of tape contact and remove quickly for topcoats.
- 4. Paint entire area with Outrageous Clearcoat.

SPECIAL NOTES:

NOTE: Clean equipment immediately after use with cleaning solvent. Dispose of in accordance to state, local and federal regulations.



HEALTH & SAFETY:

Read all warnings, first aid and safety for all components before using. Keep out of reach of children and animals. Wear a properly fitting NIOSH/MSHA approved respirator. Select positive pressure supplied respirator (TC-19C or equivalent) for isocyanates. Follow the respirator manufacturer's directions for use. Protect hands with impervious rubber gloves. Wear face, skin and eye protection. Outrageous® Custom Finishes' products are for industrial use by professional, trained painters.

٢	
	2 R I
L	

CONTACT:

OUTRAGEOUS CUSTOM FINISHES A Division of Alco Industries, Inc. 600 Nova Drive SE, Massillon, OH 44646 In the US Call: 800-321-0672 or 330-830-6000 www.outrageousfinishes.com