



AIR LINE TO RETRACT GEAR

ROBART #174

PLYWOOD MOUNT

STRUT

RETRACTED POSITION

AIR LINE TO LOWER GEAR

TEE

METAL MOUNTING STRAP

CYLINDER MOUNTS TO FRONT BULKHEAD. IT SHOULD BE A RIGID MOUNT.

ROBART #165

SILVER SOLDER #2-56 B.H.M.S TO BRACKET

ROBART #350

BALL LINK