



INSTALLATION INSTRUCTIONS

#15700 STEP LIGHT
#15701

1) INSTALLING FIXTURE TO WALL

Mount housing between wall studs and secure with screws or nails. Double head nail provided for installation.

2) ELECTRICAL CONNECTION

Remove junction box cover which socket is attached to. Install power lead through 1/2" knock out and strip black (hot) and white (neutral) wires and splice to socket wires. Make sure the colors match black to black, white to white, and green to green. Use easy connector, which is already connected with the wire of fixture. Simply insert the wire from the source into the slot of the connector. Wire should be fixed properly.

3) TRIM INSTALLATION

First, install lamp (A19 type recommended). While holding trim in hand with v-springs facing up, take thumb and index fingers on both hands to pinch the v-springs in towards one another. Insert v-springs between stamped tabs and release slowly. Push trim flush against housing.

WARNING - RISK OF FIRE. MOST DWELLINGS BUILT BEFORE 1985 HAVE SUPPLY WIRE RATED 60° C. CONSULT A QUALIFIED ELECTRICIAN BEFORE INSTALLING.

