



The 2014 A146 Universal Saddle Bag Straps are designed to allow the Wolfman Rocky Mountain, Expedition Dry, and Monarch Pass Saddle Bags to attach to virtually any motorcycle side racks manufactured. Patents Pending.

Threading instructions for the A146 Universal Saddle Bag Straps.

Thank you for purchasing Wolfman Luggage.

**\*READ THOROUGHLY BEFORE ATTACHING STRAPS TO BAGS\***

**\*The mounting is the same for both left and right bags\***

The A146 Universal Saddle Bag Strap Kit contains the following:

8-Saddle Bag Straps (4-Per Saddle Bag) FIG1

FIG1



To attach the A146 Universal Saddle Bag Straps,

1-Lay the saddle bag on its back with the wolf logo facing up. This is easiest if you separate the bags. FIG2  
Rocky Mountain Expedition Dry Monarch Pass



2-Make sure the 1"chrome slides on either side of the saddle bag are positioned away from the bag. FIG2

3-Unthread the 1"side mounting straps from the bag.

4-Reverse the 1"side mounting straps through the center or side buckles.

-On the Rocky Mountain the 1"side mounting strap goes through a 1" cam buckle.

-On the Expedition Dry the 1"side mounting strap goes through a 1" dual adjust side squeeze buckle.

-On the Monarch Pass the 1"side mounting strap goes through a heavy duty tension lock buckle.

\*\*\* NOTE the direction the 1"side mounting strap goes through the buckles of your bag\*\*\*

5-On the Rocky Mountain and Expedition Dry Saddle Bags reverse thread the 1"side mounting strap through the first 1" loop on the black patch.

6-Remove the 1" strap keeper. Squeeze the webbing in half and let it through the slot on the underside of the strap keeper. Do this for all Saddle Bags.

7-On the Rocky Mountain and Expedition Dry Saddle Bags reverse thread the 1"side mounting strap through the second 1" loop on the black patch.

8-Remove the 1" chrome slide.

\*\*\*\*\*DO NOT REMOVE the 1" side mounting straps from the Rocky Mountain or Expedition Dry Saddle Bags. \*\*\*\*\*

-Threading the A146 Universal Saddle Bag Straps

9-Lay 4 A146 Universal Saddle Bag Straps label side down, next to each of the 1" side mounting straps, that had the 1" chrome slide on it. \*\*\*Make sure the chrome bar is on top of the 3/4" webbing, as shown in FIG3. FIG3

1" Side mounting strap      Chrome slide



3/4" Webbing under chrome bar

10-Thread the 1"side mounting strap from the saddle bag through the open slot on the chrome slide. As shown in FIG3

11- On the Rocky Mountain and Expedition Dry Saddle Bags thread the 1"side mounting strap through the second 1" loop on the black patch.

12-Thread the 1"side mounting strap through the 1"strap keeper, sometimes a small screwdriver helps feed the tabbed end through the 1" strap keeper. Do this for all saddle bags.

13- On the Rocky Mountain and Expedition Dry Saddle Bags thread the 1"side mounting strap through the first 1" loop on the black patch.

14-Thread the 1" side mounting strap through the center or side buckles.  
On the Rocky Mountain the 1" side mounting strap goes through a 1" cam buckle.  
On the Expedition Dry the 1" side mounting strap goes through a 1" dual adjust side squeeze buckle  
On the Monarch Pass the 1" side mounting strap goes through a heavy duty tension lock buckle.  
\*\*\* NOTE the way the 1" side mounting strap goes through the buckles of your bag\*\*\*

15-Repeat these steps for all 4 straps on each bag. 8 per pair.  
15-Correctly threaded A146 Universal Saddle Bag Straps should look as pictured on each of our rack mounted saddle bags.

Rocky Mountain Saddle Bag. FIG4



Expedition Dry Saddle Bag. FIG5



Monarch Pass Saddle Bag. FIG6



If you have any mounting questions please contact us at 800/535-8131 or [info@wolfmanluggage.com](mailto:info@wolfmanluggage.com)

Enjoy.