



Mounting instructions for the Wolfman Enduro Carry -All 2012, Part # M0703

A properly mounted Enduro Carry-All 2012 so as to not cover the headlight. FIG 1&2

FIG 1 Front view



FIG 2 Rider view



1. Mount the Enduro Carry-All 2012 so the top straps just touch the top lip of the number plate. Fasten both the top straps around the handlebar as shown. Ensure the top straps go under the brake line. FIG 3

FIG 3



2. The bottom mounting straps are threaded inside the fork tube, under the bottom triple clamp between the fork tube and fender and through the buckle, from back to front. FIG 4

FIG 4



5. Rider view of a properly mounted Enduro Carry-All 2012 with map pocket. The map pocket can be mounted vertically or horizontally. Vertical mounting is shown. Ensure the map pocket is placed under the front brake line. FIG 5

FIG 5



6. For best results use the outside compression straps to tighten the load.

7. Maximum weight capacity: 2lbs. or 1 kilo.

8. If you have any questions please contact us at 800/535-8131 or dusty@wolfmanluggage.com. Enjoy!!!