

## Mounting instructions for Wolfman Top Rack

### HONDA CRF250L 2013-

This kit contains the following:

Quantity	Description
1	Top rack
2	6mm x 1.0 x 45mm Flat head bolts
2	8mm x 1.25 x 55mm Flat head bolts
2	1 1/8 Aluminum spacers
2	1 1/2 Aluminum spacers
1	6mm x 30mm Cone set screw
1	8mm x 30mm Cone set screw

#### **Tools required:**

Blue Loctite or a medium strength thread locker

Drill

Step drill bit or 11/16 drill bit

10mm End wrench or socket

12mm End wrench or socket

4mm Hex wrench

5mm Hex wrench

Read and understand these instructions prior to installation

**Be sure to thread lock all bolts**

**Correctly mounted top rack on a Honda CRF250L 2013 -**



**\*\*\* Install tip - Oversize the mounting holes in tail light assembly.**

1. Remove seat and rear fender.
2. Remove one each 6mm and 8mm bolt that holds tail light assembly. Install one each of the 6mm and 8mm set screw with point up. **See FIG 1**
3. Place rear fender back in place, be sure to get it in proper placement and press down on fender at set screw location. Repeat for other two bolts. **See FIG 2**

**FIG 1**



**FIG 2**



4. Remove fender and drill all four of the mark points out to 11/16. **See FIG 3**
5. Remove all bolts holding tail light assembly and allow it to rest down on rear tire. Reinstall your drilled fender.
6. With fender installed, hold taillight assembly in place and place 1 each 1 1/2 spacer in rear holes with long point pointing rearward, place 1 each 1 1/8 spacer in front holes long point pointing rearward. **See FIG 4**

**FIG 3**



**FIG 4**



7. Place top rack on top of spacers and install 1 each 8mm x 1.25 x 55mm bolts in back holes and start. Place 1 each 6mm x 1.00 x 45mm in front holes and start.
8. Check that spacers are aligned properly and tighten bolts.

**\*\*Periodically re-check all hardware to maintain rigidity and structural integrity\*\***

If you have any questions call 800/535-8131 or email [sales@wolfmanluggage.com](mailto:sales@wolfmanluggage.com)  
Enjoy!