

Mounting instructions for Wolfman
Top Rack
KTM 950 -990 ADV
Part # RTR7

This kit contains the following:

Quantity	Description
1	Top rack Part # RTR7
2	8mm x 1.25 x 70mm Flat head
2	8mm x 1.25 x 60mm Flat head

Tools required:

Anti-seize or grease

5mm Hex wrench

Read and understand these instructions prior to installation!

**THIS KIT INCLUDES STANLESS STEEL HARDWARE BE SURE TO
LUBRICATE THREADS PRIOR TO INSTALLING.**

**MOUNTING KIT PROVIDE WITH TOP RACK IS FOR MOUNTING WITH
OEM OR AFTER MARKET SIDE RACKS OR OEM GRAB HANDLES. IF NO
SIDE RACKS OR GRAB HANDLES ARE USED YOU WILL NEED 2 - 1 3/4
SPACERS FOR FRONT MOUNTING POINTS AND 2-1" SPACERS FOR THE
REAR.**

1. Mount top rack in place using 2 - 8mm x 1.25 x 70 mm in back mounting holes and 2 - 8mm x 1.25 x 60mm flat head in the front mounting holes.
2. Tighten to OEM specification.



Periodically Re-check all Nuts and Bolts to maintain rigidity and structural integrity

If you have any questions call 800/535-8131 or email sales@wolfmanluggage.com.

Enjoy!