

# USB Plug Installation:

Incorrect: Not fully seated



Correct: Fully seated into housing

