



- 1** Place the tile on the designated location and trace the perimeter with a thin permanent marker.
- 2** Set the tile aside and using a 4" diamond cup grinder, scour the concrete within the marked location and in correspondence with the location requiring adhesive as indicated in backside of tile.
- 3** Clear away the dust with a leaf blower then clean the back of the tile and the concrete with rag soaked in acetone.
- 4** Apply adhesive to back of tile (as indicated on tile). The first bead should be applied thin, 1/2" from the perimeter edge and a second thicker bead applied 1" inside of the first.
- 5** Set the tile true and square to the curb ramp and press down firmly.
- 6** While stepping down on either side of pre-formed hole, drill down 3" into concrete slab using a hammer drill and the recommended 1/4" diameter carbide drill bit.
- 7** While still applying pressure, remove the dust and any adhesive that surfaces and carefully set the supplied color-matched Tek™ Anchor with a plastic-tipped hammer. Repeat steps 6 & 7 while working across the tile from one end until all pre-formed fastener locations are completed.
- 8** Clean the perimeter of the tile and the immediately surrounding concrete with acetone making sure to remove any adhesive that has escaped from beneath the tile. Apply and smooth sealant around perimeter of tile.

