



DIMENSIONS

Panel Size:

1800mm (W) x 600mm (L) x 38mm (D)

Slats Per Panel:

12

Composition:

Real Wood Canadian Cedar



CONTENTS

Cedar Slatted Panel (Single):

1 x cedar panel

Cedar Panel Modular (Bundle):

3 x cedar panels, 3 x single slats (2 to brace the rear of the panels once fitted and 1 to cover the joints between panels if fitted side by side)

TOOLS

- Wood saw
- Screws*
- Screwdriver

*Use Naturewall stainless-steel screws to avoid discolouration and damage to your panels.

PREPARATION

Please wear appropriate PPE (For example gloves, goggles and a dust mask).

PROTECTING YOUR PANELS

We recommend treating your panels with our Clear UV Protection Oil, 12 weeks after fitting your panels. There may be some slight greying or lightening depending on the weather during the first 12 weeks, however the UV Protection Oil will darken the wood and bring it back to the original cedar tone. Oil the panels every 2-3 years for best protection.

INSTALLATION

1. Position your first panel. We recommend fitting your first panel 50mm above ground level.
2. Use spirit level to ensure your first panel is level.
3. Use stainless steel screws to fix first panel in place. We recommend a minimum of 8 screws per panel, 4 screws at each end, evenly spaced. Top tip: position the screws between the horizontal slats of the panel using the longer screwdriver bit we provide in our box of screws, (sold separately).
4. Position your second panel on top or next to your first panel. Use stainless steel screws to fix your second panel in place, as per step 3. Position your third panel on top or next to your first panel. Use stainless steel screws to fix your third panel in place, as per step 3 and step 4.

You can repeat the above steps until you have created the desired fence height and width.