

CEDAR PANELS FITTING GUIDE



Transforming your garden has never been easier. Create a beautiful boundary with Cedar Panels in hours, not days, by following these simple steps.

WHAT YOU'LL NEED

- Cedar Panels
- Fence posts or existing fence
- Exterior Screws*
- Screwdriver
- Spirit level

YOU MAY ALSO NEED

- Pencil
- Square tool
- Fine-toothed hand saw
- Clear UV Protection Oil*

(*Exterior Screws and Clear UV Protection Oil sold separately.)

WHAT'S INSIDE YOUR PACKAGE

Cedar Slatted Panel (Single): one Cedar panel.

Cedar Panel Modular (Bundle): three Cedar panels, three single slats (two to brace the back of the fence after fitting and one to cover the joints between the panels if installed side by side).

GET TO KNOW YOUR PANELS

- Panel size: 1800mm (W) x 600mm (L) x 38mm (D)
- Slat size: 44mm (W) x 18mm (D)
- Gap between each slat: 6mm
- Slats per panel: 12
- Panel coverage: 1.09m²

PLAN AHEAD

1. Space your fence posts 1800mm apart. Alternatively, attach your panels to an existing fence.
 2. Unbox all your packages and check the panels.
 3. Decide on your layout and cut the panels to size if needed.
-



MAKE THE CUT

1. Measure where you want to cut. Take care not to weaken the panel and be mindful of the joining batons.
2. Mark a straight line with a square tool and a pencil.
3. Cut the panel with a fine-toothed hand saw.

BRING IT TOGETHER: BUILDING YOUR MODULAR BUNDLE

1. Lay your panels face down and align.
2. Use two individual slats to brace the back of the panels and attach them together.
3. Use exterior screws to secure in place.

BRING IT TOGETHER: INSTALLING YOUR PANELS

1. Wear appropriate PPE, such as gloves, goggles and a dust mask, during installation.
2. Position your first panel – aligned to the posts or against the fence – 50mm above ground level.
3. Check it's straight with a spirit level.
4. Fix it in place with our exterior screws. Top tip: use at least eight screws per panel and position them between the slats.
5. Position your next panel above or next to your first panel. Use the same method to fix it in place.
6. Repeat for each panel.

Top Tip: Fix an individual slat in place using exterior screws to conceal the panel joints.

FUTURE-PROOF YOUR FENCE

1. Treat your panels with our Clear UV Protection Oil 12 weeks after installation. Important: weather conditions may cause the panels to grey or lighten, but the oil treatment will darken the wood and restore its cedar tone.
2. Oil the panels every 2-3 years for the best protection.

LAST BUT NOT LEAST

Stand back and marvel at your beautiful panels.

We're here to help with your outdoor transformation.

If you have any questions about installing Cedar Panels, please contact our customer service team at info@naturewall.com.

