

# SLATWALL GRAND FITTING GUIDE



Transforming your room has never been easier.  
Create your dream wall with SlatWall Grand in hours,  
not days, by following these simple steps.

## WHAT YOU'LL NEED

- SlatWall Grand panels
- Tape measure
- Spirit level

## YOU MAY ALSO NEED

- Pencil
- Square tool
- Fine-toothed hand saw
- Sharp utility knife

## INSTALLATION WITH SCREWS

- 15 (3.5mm x 35 mm) screws per panel
- Screwdriver
- 45mm battens (optional)
- 45mm mineral wool (optional)

## INSTALLATION WITH ADHESIVE

- Hybrid Grab Adhesive
- Sealant gun

## GET TO KNOW YOUR PANELS

- Panel size: 2400mm or 3000mm (H) x 600mm (W) x 21mm (D)
- Slat size: 50mm (W) x 12mm (D)
- Slats per panel: 10
- PET felt backing: 9mm (D)
- Panel coverage: 1.44m<sup>2</sup> or 1.8m<sup>2</sup>

## PLAN AHEAD

1. Remove any screws, nails or other fixtures from your wall.
2. Make sure your wall is clean, smooth and level.
3. Unbox all your packages and check the panels.
4. Decide on your layout and cut the panels to size if needed.



## MAKE THE CUT

---

1. Measure where you want to cut.
2. Mark a straight line with a square tool and pencil.
3. Cut the panel horizontally with a fine-toothed hand saw or cut the felt backing vertically with a sharp utility knife.

## FORM A STRONG BOND

---

### With screws:

1. Install your first panel by aligning 15 screws in rows of three and fixing it to your wall. Pick screws in a colour that coordinates with your felt backing and use the appropriate fixings for your wall (e.g. wall plugs).  
Top tip: for 2400mm height panels, space the rows 575mm apart. For 3000mm height panels, space the rows 725mm apart. Make sure the outer screws are 50mm from the panel's edge.
2. For maximum (Class A) acoustic performance, install the panels onto 45mm (D) battens with 45mm mineral wool between each batten.
3. Repeat for each panel.

Important: When applying to the ceiling, it's essential that you use our Hybrid Grab Adhesive and screws for secure installation. Begin by applying Hybrid Grab Adhesive to the back of each panel, then firmly press the panels in place. You can then secure the panels by affixing screws to structural points such as joists.

### With Hybrid Grab Adhesive:

1. Apply Hybrid Grab Adhesive in three wavy lines on the back length of your first panel.  
Top tip: one tube of adhesive covers three panels.
2. Position the panel against your wall and press firmly to secure it.
3. Repeat for each panel.

## DO AS YOU SEE FIT

---

If adding fixtures and fittings, such as shelves or TV brackets, drill through the panel and sub wall, then use appropriate wall plugs and screws.

## LAST BUT NOT LEAST

---

**Stand back and marvel at your beautiful wall.**

We're here to help with your wall transformation.

If you have any questions about installing SlatWall Grand, please contact our customer service team at [info@naturewall.com](mailto:info@naturewall.com).

