

EXDL-0

Installation Instructions



Suitable For Use with Telguard LTE, 3G/4G and CDMA Products

Kit Contents:

- Low Profile Antenna
- Connector-adaptor
- Mounting bracket

Note: Appropriate length cable must be ordered separately. Visit: www.rfmax.us

Antenna Installation Considerations:

- The Antenna and Antenna Cable should be located inside of the building, within the protected area.
- If the Antenna and Antenna Cable are outside the protected area, proper measures should be followed as prescribed by overseeing jurisdiction based on installation type.

Antenna Installation Sequence:

- Initial Installation: Follow installation instructions for Telguard device and refer to mounting instructions below.
- Retrofit: Follow mounting instructions. Remove existing whip antenna, and replace with antenna cable.

Mounting Instructions:

- 1) Attach mounting bracket in an area of adequate signal strength and to a substantial side structure.
- 2) Slip threaded antenna stem through hole in top of bracket
- 3) Secure antenna from below with lock washer and nut supplied with kit
- 4) Tighten securely but do not over tighten or strip threads
- 5) Attach connector-adaptor to threaded antenna stem
- 6) Attach one end of cable, or any Telguard cable up to 100ft. long, to the connector-adaptor and securely tighten. Take appropriate measures to waterproof this connection as needed.
- 7) Connect other end of cable to the Telguard device.

Important: Antenna must be mounted in a vertical orientation.

For antennas & cable kits for Telguard cellular communicators, visit: www.rfmax.us