

## Fitting of latch and hinges with plastic trim edges.

Carefully remove the pvc edge strips if required to allow the door to be shaped to suit the frame - this process may not be necessary.

Refit these trims if they have been removed for the above process but make sure your door and therefore the trims are cut to the correct height.

Choose where you intend to fit the handles and position the latch face against the pvc edge trim, mark out accordingly, drill 4 corners of where the latch plate will be then Stanley between these holes, be careful not to allow the Stanley blade to slip.

Hinge screws are simply drilled carefully through the pvc hinge trim in to the door edge and there is no need to cut out for hinges on the pvc but depending on the frame they may need a very slight frame rebate/housing to suit the hinges.

