

Fitting Instructions

1. Remove rubber seals from aluminium sill section. Measure width between inside faces of the door frame rebate and cut aluminium section to this size (see illustration).

2. Notch front corners of the Threshex sill to fit it neatly around the door frame.

3. Cut rubber seals to length and insert into aluminium. The diagram on the front of the label shows the direction of the seal for inward opening doors. For outward opening doors the rubber seal must be reversed.

4. This sill requires an underdoor clearance of 17mm. If necessary, remove door and trim to allow for this, ensuring bottom of door is smooth to avoid damage to rubber seal.

5. Position the assembled sill between the door frame and mark fixing points through countersunk holes. Remove sill, drill fixing holes and insert plugs.

6. Apply sealing compound (Exitex Elast-O-Sealant) to underside groove at front and back of sill and screw sill into place.

4. Fix the grey button and screw provided to the lockside of the door frame (see illustration).

Threshold Section Cut to this length

