



Installation instructions:

Step 1- Remove inner rubber piece of cup holder

Step 2- Remove both torx screws from bottom of cup holder

Step 3- Pull up on entire cup holder piece to pop out clips

Step 4- Once cup holder piece is out you can remove factory cubby

Step 5- Factory cubby gator clips on back side need to be transferred to the new carbon cubby before installation

Step 6- Once clips are installed, carbon cubby can be pushed into factory spot

Step 7- Put cup holder piece back into place

Step 8- Fasten both torx screws and install inner rubber piece