

FREE ZIP 2P SET UP INSTRUCTIONS



Cutting Guylines:

Door guylines are pre-cut to 12" (30 cm) and attached to the sewn in adjustable linelocs for you. Four optional 48" (122 cm) guylines are also provide for use in intense weather.

Setup Instructions:

Splash-up can occur when camped on hard packed surfaces during heavy rain. Our bathtub floor and overhanging canopy helps to keep mud and water from splashing up into your tent, but for best results please choose camp spots on leaves or pine needles when possible. Remove any pointy twigs and sharp objects to protect your tent floor but leave as much rain-dampening cushioning as possible to minimize the potential of splash-up.

- 1) Insert the the tips of the tent poles into the rings at the corners and peaks of the tent. The center part of the poles will create an "X" shape on each side of the tent. Make sure that the tips at the peaks of the tent are criss-crossed. Crossing the tips at the peak helps keep the tent splayed open.
- 2) On each side, clip the 4 exterior wall clips to the tent poles to create a rectangular shape.
- 3) Take the two hooks in the middle of the tent wall and clip them to the outer most pole where the two poles come together to form an "X." The clips should be run on either side of lower pole, helping it stay stabilized.
- 4) Repeat this step on the other side.
- 5) If conditions warrant it, stake out the storm doors, and/or the corners. In strong wind, attach the provided optional guylines to the wall loops, using a maximum of ten stakes for the best stability.

Storm Doors:

Any of the four doors can be clipped down, or rolled up independently. The storm doors can be clipped down to the front center guylines, or rolled up depending on the weather. Leave at least one down-wind door open for air flow unless the weather is bad.

Seam Sealing:

All Zpacks shelters have taped seams and bonded tie outs! No seam sealing necessary.