

Instructions:

Ensure all of the surfaces have been washed thoroughly and all contaminants have been removed before starting.

Wear latex gloves, eye protection, a mask and work in a well-ventilated area.

- 1 Apply the prep fluid solution liberally with a clean cloth by either spraying directly onto the surface and then buffing clean or by spraying onto the cloth directly. Ensure surfaces are fully dried. One cloth should be enough for this stage.
- 2 Apply a few drops of ceramic to the white applicator pad provided
- 3 Apply to surface, working on one section at a time in a cross hatch method (horizontally, then vertically).
- 4 Allow to dwell for 1 to 2 minutes until you can see a rainbow appearance on the surface
- 5 Take a clean microfibre cloth, fold twice, and gently buff the remaining coating on the surface until a clear, rainbow and smear free finished is achieved. The key here is to not buff too hard but simply to remove any signs of rainbow and/or smears only. Use a new clean section of cloth for each section.
- 6 Allow the coating to cure for a minimum of 4 hours before using the vehicle again. Ideal curing is 24 hours if possible.



www.Aqueous-Guard.com

01622 717 755