



## SELF ADHESIVE FOAM

- 1) Make sure all surfaces upon which the product is to be used are clean and free from dust, dirt and grease.
- 2) If necessary rub down with white spirit and dry off thoroughly.
- 3) Working from the top adhere the seal to the vertical frame of the door or window so that the seal can be compressed by closing action.
- 4) Work downwards and smooth down to ensure seal is properly affixed.
- 5) Cut to exact length using scissors. Repeat for horizontal sections,